




NG100H AC SERVO MANUAL



PROLINECNC

AC Servo Manual



Safety Caution

Before product storage, installation, wiring, operation, inspection or maintenance, the user must be familiar and comply with the following important matters to ensure to use the product safely .



Danger Misoperation would cause danger and personal injury.



Attention Misoperation may cause danger, personal injury and damage the equipment.



Prohibition Behavior is strictly prohibited, otherwise it will lead to equipment damage or can not be used.

١. Application



Danger

- Forbidden to use the product when it is exposed to water gas, corrosive gas and combustible gas. Or it could cause an electric shock or a fire.
- Forbidden to use products in places with more direct sunlight, dust, salt and metal powder.
- Forbidden to use products in places where water, oil and medicine are dripping.

٢. Wiring



Danger

- Please ground the grounding terminal reliably. Poor grounding may cause electric shock or fire.
- Please do not connect ٣٨٠ V power supply to ٢٢٠ V servo drives, otherwise it will cause equipment damage and electric shock or fire.

- The U、 V、 W motor output terminal and the motor wiring terminal must be connected one-to-one correspondence, otherwise the motor may cause equipment losing and casualties caused by the over speed vehicle.
- Please fasten the power supply and motor output terminals, otherwise it may cause fire.

۳. Operation



Caution

- When the mechanical equipment starts operation, it must match proper parameters. If it does not adjust to the appropriate setting values, it may cause the mechanical equipment to lose controlling.
- Before starting operation, please confirm if you can start emergency switch shutdown at any time.
- Please test whether the servo motor is running normally without load firstly, and then connect the load to avoid unnecessary loss.
- Do not switch on and off power frequently, otherwise it will cause drive overheating.

۴. Working



Prohibition

- When the motor is running, it is forbidden to touch any parts in rotation, otherwise it will cause casualties.
- When the equipment is in operation, it is forbidden to move connecting cables, otherwise it will cause injury to the person or damage to the equipment.

CONTENT

Chapter 1 Product Inspection And Installation	- 1 -
1.1 Product Inspection.....	- 1 -
1.2 Product Front Panel.....	- 2 -
1.3 Product Installation.....	- 3 -
Chapter 2 Servo Specifications.....	- 6 -
2.1 Servo Drive Specification.....	- 6 -
2.2 Servo Drive Naming Rule.....	- 7 -
2.3 Servo Motor Naming Rule.....	- 7 -
2.4 Servo Motor And Matched Servo Drive List.....	- 8 -
Chapter 3 Drive And Motor Dimension.....	- 9 -
3.1 Drive Dimension.....	- 9 -
3.2 Motor Dimension.....	- 10 -
Chapter 4 Drive System Wiring And Introduction.....	- 12 -
4.1 Servo System Wiring.....	- 12 -
4.2 Servo driver terminals Introduction.....	- 14 -
4.3 Main Circuit Terminal.....	- 15 -
4.4 CN1 Control Signal Terminal.....	- 17 -
4.5 CN2 Encoder Signal Terminal.....	- 30 -
4.6 CN3 And CN4 Terminal Definition.....	- 31 -
4.7 Anti-jamming Countermeasures of Power Wiring.....	- 34 -
Chapter 5 Running Mode And Controlling Wiring.....	- 38 -
5.1 Position Control Mode.....	- 39 -
5.2 Speed Control Mode Wiring.....	- 40 -
5.3 Torque Control Mode.....	- 48 -
5.4 Origin Regression Function And Relevant Parameters Introduction....	- 51 -
5.5 Pre-operational Inspection.....	- 54 -
Chapter 6 Operation And Display.....	- 55 -
6.1 Drive Panel Introduction.....	- 55 -
6.2 Main Menu.....	- 56 -
6.3 Steps To Set Parameters.....	- 56 -
6.4 Status Monitoring.....	- 57 -
6.5 Analog Quantity Zeroing Adjustment.....	- 58 -
6.6 Encoder Selection.....	- 58 -

6.9 How To Recover Default Parameters - 59 -

Chapter 9 Parameters..... - 60 -

9.1 PA Group..... - 60 -

9.2 P# Group Parameters For Multifunctional Terminals..... - 81 -

9.2.1 Parameter Table..... - 81 -

9.3 P# Group Parameters For Internal Position Command..... - 91 -

Chapter 10 Error Code..... - 98 -



Chapter 1 Product Inspection And Installation

1.1 Product Inspection

This product has made the complete function test before delivery, Please check below points after unpacking. (for prevented the product to be abnormal owing to shipping process, please make detail inspection as the following items after breaking the seal:)

- (Inspect the types of servo driver and servo motor and ensure that are the same types in the order form.) The purchased product is identical with your desired.
- Please do not power it on if there is any damage on the product appearance.
- Inspect the parts of servo driver and servo motor to see any loosen parts such as loosened or fallen off screw.
- Rotate the servo motor shaft by hand and should be smooth rotation.


However, the servo motor with holding brake is unable to rotate directly. If there is any break down item or abnormal phenomenon mentioned above, please contact with the dealer immediately.

If there is any discrepancy, please contact the purchasing agents.

PROLINECNC

1.2 Product Front Panel

Applicable types: - 40 - 70



Pic 1.2 Front Panel Introduction

Item	Terminal	Introduction
①	CN1、CN2	Communication terminal
②	CN1	Input and output control signal terminal
③	CN2	Encoder signal terminal
④	L1、L2	Power supply terminal
⑤	CHARGE	Bus voltage indicator. It is used to indicate the bus capacitance in a charged state. When the indicator lights on, even if the power supply is off, the internal capacitor of the servo unit may still have a charge. Therefore, do not touch the power terminal when the lights on to avoid electric shock.
⑥	P、D、C、N	Regeneration resistance terminal
⑦	U、V、W	Servo motor UVW connection terminal
⑧	PE	Ground terminal

1.3 Product Installation

1.3.1 Servo Drive Installation

- Installation direction

The normal mounting direction of the servo drive is vertical and upright..

- Fixed installation


During installation, please tighten the 4 pcs M4 fixing screws at the back of the servo drive.

- Grounding

Be sure to ground the driver grounding terminal, otherwise there may be a risk of electric shock or interference to produce wrong action.

- Wiring requirement

When connecting the drive, please wire the cable down (refer to the below picture) to avoid any liquid attached on the cable and then it flows into the drive along with the cable.



Please connect the cable
in the downward direction

Pic 1.3 Wiring Direction Requirement

- Installation interval


Refer to pic 1.3 for the distance between drives and installation intervals with other devices, and please note that the picture indicates the smallest size, in order to ensure the performance and life of the drives, please leave the full installation interval as far as possible.

- Cooling

The servo drive adopts natural cooling mode and forced heat dissipation mode.

- Installation considerations

Prevent dust or iron chips from entering the servo drive when installing the electrical controlling cabinet.



Pic 1.3 Installation Interval

1.3.2 Environment Condition For Installation

Since the environment conditions for servo driver installation have the direct influence to the normal function and service life of the servo driver, therefore the environment conditions must be conformed to the following conditions:


- Ambient temperature: 0 to 40°C ; Ambient humidity: less than 80% (no condense).
- Storage temperature: -20 to 60°C ; Storage humidity: less than 95% (no condense).
- Vibration: less than 0.5G .
- Preventive measure shall be taken against raindrop or moist environment.
- Avoid direct sunlight.
- Preventive measure shall be taken against corrosion by oil mist and salinity.
- Keep away from radioactive and inflammable substances.
- Free from corrosive liquid and gas.

1.3.3 Servo Motor Installation

- For horizontal installation: In order to prevent water, oil, etc. from entering inside of the servo motor, please put the cable connector downward.
- For vertical installation: if the shaft of the servo motor is in upward direction with a speed reducer, some prevention measure shall be taken against entering inside of the servo motor by oil come from the speed reducer.
- In case of installation or removing the servomotor, please do not hit the servo motor with a hammer, otherwise the shaft and the encoder can be damaged.

1.3.4 Motor Rotation Direction Definition

The motor rotating direction description in this handbook is defined as facing the shaft of the servo motor, if the rotating shaft is in counterclockwise direction will be called as positive direction, or in clockwise as reversal direction.



Pic1.4 Motor Rotation Direction

PROLINECNC

Chapter 2 Servo Specifications

2.1 Servo Drive Specification


Model	— ④ —	— ⑤ —
Power	0.05KW~0.5KW	0.75KW~1KW
Main Circuit	1 phase AC220V-10%~10% 50/60Hz	
Control Mode	① : Position. ② : Speed. ③ : Torque. ④ : Position and speed. ⑤ : Position and torque. ⑥ : Speed and torque	
Protection Function	Over speed, Over voltage, Under voltage, Overload, Abnormal of main power, Abnormal encoder, Out of position error etc.	
Monitor Function	Speed, Current position, Command pulse accumulation, Position deviation, Motor torque, Motor current, Running state etc.	
Control Input	① : Servo on ② : Alarm clearance ③ : CCW drive inhibition ④ : CW drive inhibition ⑤ : Deviation counter clearance ⑥ : Command pulse inhibition ⑦ : CCW torque limit ⑧ : CW torque limit	
Control Output	Servo ready/Servo alarm/Positioning completion/Mechanical braking	
Regeneration Braking	Built-in/ Built-out	
Load	Less than ④ times of motor torque	
Display	⑥ LED digital display and ④ keys	
Communication	RS485	
Position Control Mode	Input Mode	① : pulse+direction
		② : CCW/CW pulse
		③ : A/B phase orthogonal pulse
		④ : Internal position control
	Electronic gear ratio 1-32768/1-32768	

2.2 Servo Drive Naming Rule



Serial No.	Definition
①	DS series ac servo drive
②	Power: 1000,00KW~1KW; 200:1KW~3KW;
③	H: High performance and for 17-bit single/multi-turn absolute encoder.
④	The branch power range below 1KW: 20:0,00KW~0,2KW; 30:0,2KW~0,30KW.
⑤	Customization

2.3 Servo Motor Naming Rule



Serial No.	Definition
①	series ac servo motor
②	Flange: 20(mm), 30(mm), 40(mm), 50(mm), 60(mm), 70(mm)
③	Rated torque($\times 0,1$ N.m): 02=2, 03=3N.m.
④	Rated speed($\times 100$ rpm): 30=3000rpm.
⑤	Encoder resolution: A1: 17-bit single turn absolute. A2: 17-bit multi-turn absolute.
⑥	TA: AMP connector.
⑦	B: with a brake, Null: without a brake.



1. The code $\cdot \gamma \xi \gamma \cdot$ means the motor rated torque is $\gamma, \xi \text{ N.m}$ and rated speed is $\gamma \cdot \cdot \cdot \text{rpm}$.

2. The rated power: $P = \cdot, \gamma \cdot \xi \gamma \times N \times T = \cdot, \gamma \cdot \xi \gamma \times \gamma, \xi \times \gamma \cdot \cdot \cdot = \gamma \circ \gamma, \wedge \xi \text{ W} \approx \cdot, \gamma \circ \text{KW}$.
 T =rated torque, N =rated speed.




2.4 Servo Motor And Matched Servo Drive List

Table 2-1

Flange	Model	Power (W)	Speed (RPM)	Matched Drive	Encoder
60mm	NG60-0.630A6-TAB)	200	3000	-E6	17-bit single turn absolute encoder
	NG60-0.123A6-TA(B)	400	3000		
80mm	DN80-0.253A6-TA(B)	700	3000	-V6	
	DN80-0.323A6-TA(B)	1000	3000		

Table 2-2


Flange	Model	Power (W)	Speed (RPM)	Matched Drive	Encoder
60mm	NG60...630A1-TAB)	200	3000	-E6	17-bit multi- turn absolute encoder
	NG60...630A1-TA(B)	400	3000		
80mm	DN80...630A1-TA(B)	700	3000	-V6	
	DN80...630A1-TA(B)	1000	3000		



Chapter 3 Drive And Motor Dimension

3.1 Drive Dimension

The user can install the servo drive with the bottom plate and the installed direction is perpendicular to the installation facing. Recommended to cool the servo drive with fan or natural cooling.




Pic 3.1 - 3.1 Dimension



- 3.1 - doesn't have the heat sink with a fan

3.2 Motor Dimension

- Flange 60mm




Pic 3.2 Flange 60mm And Table 3-1

Model	NG6...63.A6-TA	NG6...133.A6-TA	NG6...193.A6-TA
L (mm)	--	90	--

PROLINECNC

● Flange 80mm



Pic 3,3 Flange 80mm And Table 3-3


Model	NG80-0133-A7-TA	NG80-0233-A7-TA	NG80-0333-A7-TA
L (mm)	--	96	113,0

PROLINECNC

Chapter 4 Drive System Wiring And Introduction

4.1 Servo System Wiring

4.1.1 Servo Drive Wiring



Pic 4.1 Servo System Wiring

4.1.2

Wiring Introduction

Wiring Introduction

Wiring Notes:

- The control cable length should be less than 3 meters and the encoder cable length 3 meters.
- Check that the power supply and wiring of L¹, L² are correct.
- Please do not connect to 3^φ V power supply.
- The output terminals(U,V,W) must be connected with the servo motor connections(U,V,W) correspondently, otherwise the servo motor will stop or over speed. However, by exchanging three-phase terminal cannot cause the motor to reverse; this point is different with asynchronous motor.
- Earthed wiring must be reliable with a single-point connection.
- Pay attention to the correct direction of freewheel diode which is connected with the delay at the output terminal, other can cause the output circuit breakdown.
- In order to protect the servo driver from noise interference that can cause malfunction, please use an insulation transformer and noise filter on the power lines.
- Wiring the power cables(power supply , main circuit ,etc) at a distance over 30cm away from the control signal cables, do not lay them together.
- Install a non-fuse circuit breaker that can shut off the external power supply immediately for in case of the servo driver fault.

4.1.3 Electric Wire Specifications


Connect Terminal	Symbol	Wire Specification
Main Power Supply	L ¹ 、L ²	1.0~1.5mm ²
Servo Motor	U、V、W	1.0~1.5mm ²
Ground	⊕	1.0~1.5mm ²
Control Signals	CN ¹	≧ 0.12mm ² (AWG ²⁶), Shielded.
Encoder Signals	CN ²	≧ 0.12mm ² (AWG ²⁶), Shielded.
Regenerative Resistors Terminals	P、D/P、C	1.0~1.5mm ²



- ◆ Must use a twisted pair wire cable for the encoder signal wiring. If the encoder signal cable is too long ($> 10\text{m}$), in which the encoder power supply can be insufficient, may use multi wires or thick wire for the power supply wiring.



4.2 Servo driver terminals Introduction



Pic 4.2 Drive Terminals




◆ The above picture shows the pins arrangement of the drive.

PROLINECNC

4.3 Main Circuit Terminal

4.3.1 Main Circuit Terminal Introduction



Pic 4.3 Main Circuit Terminal

Terminal Name	Symbol	Detailed Explanation
Main Power Supply	L ¹ 、L ²	Connect to external AC power supply , 3 phase 220VAC -10%~+10%, 50/60Hz.
	NC	Null
Regenerative Resistance	P、D	When use the built-in resistor,please connect P and D.
	P、C	When the external regeneration resistance is required, please disconnect P and D and crossover it to terminal P and C. Leaving N disconnected.
Servo Motor	U、V、W	UVW phase output to servo motor.
		Ground with servo motor and power supply.




◆ The built-in resistor has been set as default by factory: P and D connector are in short-cut condition.

4.3.2 Regeneration Resistance Connection

If use the built-in resistor, please connect P and D(a 4 pins connector for built-in resistor has been set by factory, so you can insert it to the terminal directly), as picture A showed.

When an external regeneration resistance is connected to the servo drive, the short circuit between terminal P and D must be disconnected. Then the external regeneration resistance could be connected between P and C, and leave N alone, as picture B showed.



Pic A

Pic B



- ◆ Do not connect the external brake resistance to the positive and negative poles of the bus P、N, otherwise it will cause explosion and fire.
- ◆ Must be over minimum resistance value at $\geq 10\Omega$. Otherwise it would cause drive alarm or damage.
- ◆ Please install external brake resistance on non-combustible materials such as metal.

PROLINECNC


4.4 CN\ Control Signal Terminal

4.4.1 CN\ Terminal Introduction

The CN\ connector DB44 plug provides the signals interfaced with the host-controller. The signal includes:

- 16 programmable input terminals
- 16 programmable output terminals
- Analog command inputs
- Pulse command inputs


4.4.2 CN\ terminal pin distribution



Pic 4.4 CN\ Terminal Pin Distribution



◆ A 24-26 AWG cable is recommended.



Pic 4.1 CN1 Terminal

4.4.3 Position Instruction Input Signal

Signal Name		Pin No.	Function
Position Pulse Instruction	PULS+	5	High speed photo isolation input.
	PULS-	21	Working mode is set by parameter PA14:
	SIGN+	6	
	SIGN-	22	
	PULLHI	7	External 24V power input interface of the instruction pulse.
	GND	11/12	Internal digital signal ground.

The output circuit of instruction pulse of the upper device side can be selected from the differential output or collector open circuit output . Its maximum input frequency and minimum pulse width are shown in the following table:


pulse mode	maximun-frequency (pps)	Minimum pulse width(us)
differential output	0.0k	1
collector open circuit	2.0k	2,0



- ◆ If the output pulse width of the upper device is less than the minimum pulse width, it will cause the drive to receive error pulses.
- ◆ The terminal between PULS+ and PULS-/SIGN+ and SIGN- only support below 0V signal. If over than 0V, it needs to connect external resistances.

Input Circuit Of Pulse Instruction Diagram


1) When it is differential mode:




2) When it is collector open mode:

A) For internal 24V power sources:

- Common Anode Connection, for example: Mitsubishi PLC.




- Common Cathode Connection, for example: Siemens PLC.




B) For external power supply:

Case 1: To use internal resistance of the drive (recommended).

- Common Anode Connection:




- Common Cathode Connection:




Case 1: To use external resistance of the drive.

● Common Anode Connection:



● Common Cathode Connection:



◆ How to calculate the value of resistance R1 :

$$\frac{V_{CC} - 1.0}{R_1 + 240} = 1.0 \text{ mA}$$

Table 4-1 R1 Recommendation

VCC Voltage	R1	Power
24V	2.4KΩ	0.05W
12V	1.0KΩ	0.05W

4.4.4 Digital Quantity Input And Output Signal

Signal Name		Pin No.	Function	Introduction
Digital Input	DI ¹	20	servo enable	Optocoupler input and function can be programmable. Defined by parameter P ^r group(P ^r -0~P ^r -17). The input voltage of COM is both of common positive and negative terminal. And input signal voltage is 12~24V. In position mode (internal position mode) and non-position mode ,please connect 24V to pin 1, DI ⁰ to pin 22, DI ⁶ to pin 22. Or to connect 0V to pin 1, DI ⁰ to 0 pin ,DI ⁶ to pin 2.
	DI ²	4	alarm clearance	
	DI ³	19	CW drive inhibition	
	DI ⁴	3	CCW drive inhibition	
	DI ⁰	18	Forward external torque limit	
	DI ⁶	2	Reverse external torque limit	
	DI ⁷	17	Zero-speed clamp	
	DI ⁸	1	Zero instruction	
	PULS-	21	In position mode (internal position mode) and non-position mode	
	SIGN-	22		
	PULS+	0		
	SIGN+	6		
	PULLHI	7		
	COM	16	Common end of digital input signals	
Digital Output	DO ¹ +	31	Servo ready	Photo isolation output. Function can be programmable. Defined by parameter P ^r group (P ^r -20~P ^r -23).
	DO ¹ -	32		
	DO ² +	33	Alarm output	
	DO ² -	34		
	DO ³ +	30	Zero speed output	
	DO ³ -	36		
	DO ⁴ +	37	Position arrival	
	DO ⁴ -	38		
	DO ⁰ +	39	Speed arrival	
	DO ⁰ -	40		
	DO ⁶ +	41	Torque arrival	
	DO ⁶ -	42		


Internal Power Output	•V	22	Internal •V	Internal 0V power output and the max output current 2.0mA.
	0V	1	Internal 0V	
Internal Isolated Power Output	E•V	23	Internal •V	Internal isolated 24V power output and the voltage range is 20V~28V and max output current 1.0mA.
	E24V	24	Internal 24V	

● Input Circuit Of Digital Quantity Diagram


For DI1 as an example(the DI1~DI16 interface circuit is the same):

) When the upper device is relay output:

A) For internal 24V power supply:




B) For external 24V power supply:




▼ When the upper device is collector open output :

A) For internal 24V power supply:



B) For external 24V power supply:




Note:

- ◆ Do not support PNP mixed with NPN input.


● Output Circuit Of Digital Quantity Diagram

For DO¹ as an example(the DO¹~DOⁿ interface circuit is the same):

1) When the upper device is relay input:



2) When the upper device is optocoupler input:



- ◆ Be sure to connect a continuation diode when the upper device is a relay, otherwise it may damage DO ports or cause strong signal interference.
- ◆ The maximum allowable voltage and current capacity of the optocoupler output circuit in the servo drive are as follows:
 - Voltage: DC³•V
 - Current: DC²•mA


4.4.2 Analog instruction signal

Signal Name		Pin No.	Function
Analog instruction input	AS+, AT+	24	Analog velocity/torque input, range: $-1 \cdot V \sim +1 \cdot V$.
	AS-, AT-	9	
	AGND	20	


Pulse Instruction Input Interface Diagram

Two input types: differential (recommended) and single-end. Speed and torque share one analog input at range from $-1 \cdot V$ to $+1 \cdot V$ with resistance approximately at $1 \cdot K\Omega$. The existence of zero bias in the analog input is normal and can be compensated by parameters.

1) When it is analog differential input:




2) When it is analog single-end input:




4.4.6 Output Signal Of Encoder Frequency Division

Signal Name		Pin No.	Function
General	AO+	28	A phase frequency division output signal
	AO-	13	
	BO+	29	B phase frequency division output signal
	BO-	14	
	ZO+	30	Z phase frequency division output signal
	ZO-	15	
	CZ-OUT	27	Z signal collector open circuit output
	GND	11,12	Internal digital signal ground
	5V	8	Internal 5V power and the max current output is 200mA.
	0V	23	
	PEL	Metal Cover	

The output circuit of the encoder frequency division outputs a differential signal. Usually, it feedbacks signal when the position control system is formed for the upper device. At the upper device side, please use a differential or optocoupler to receive it and the maximum output current is 20mA.



The output circuit of encoder Z phase division can realize through an open circuit signal of collector. Usually, it feedbacks signal when the position control system is formed for the upper device. On the upper device side, please use the photocoupler circuit, relay circuit or bus receiver circuit to receive it.



◆ Please connect the 0V ground of the upper device to the GND of the drive and use the twisted pair shield wire to reduce the noise interference.


PROLINECNC

4.4.5 Motor Brake Connection

The brake lock is the mechanism that prevents the servo motor shaft from moving when the servo drive is in non-enabled state, so that the motor keeps the position locked and the moving part of the machinery will not move because of itself or external force.

Brake Signal Circuit Diagram

The brake connection of the input signal without polarity, but it needs users to prepare a 24V power supply. An example of the standard connection between the brake signal BK and the 24V power supply is shown below:



Pic 4.5 Brake Signal Connection



- ◆ The brake mechanism built into the servo motor is a fixed special mechanism of non-electric action type, which can not be used for braking purposes. Only when the servo motor is kept in a stop state can it work.
- ◆ The brake coil has no polarity.
- ◆ After the servo motor stops, the servo signal (Servo On) should be cut off.
- ◆ When the motor with the built-in brake is running, the brake may make a “click” sound, which has no effect on its function.


When the brake coil is electrified (open state of the brake), flux leakage may occur at the shaft end and other parts. Therefore the nearby devices might be interfered..

- ◆ It is forbidden to share the power supply with other electrical appliances, which is to prevent the voltage or current from decreasing resulting to the wrong work due to other electrical appliances.
- ◆ Above 1.0 mm² cable is recommended.

4.5 CN Encoder Signal Terminal

4.5.1 CN Terminal Introduction

The encoder signal connector CN connects with the servo motor encoder. A 6 pins plug is used. The pin chart is:




Pic 4.5 CN Encoder Signal Terminal

4.5.2 CN Signal Introduction

Signal Name		Pin No.	Function
Encoder Power Supply	0V	0	Use 0V power supply (Provided by servo driver). If the cable is longer than 10m, in order to prevent encoder from voltage dropping down, it is better to use multi wires or thick wires for power line and ground line.
	0V	6	
Absolute encoder communication positive end	SD+	1	Absolute encoder communication positive end
Absolute encoder communication negative end	SD-	2	Absolute encoder communication negative end
Null	NC	3	Reserve
Null	NC	4	Reserve
Shielded layer	Metal cover		Connect to the shielded layer of the encoder cable

4.6 CN[∞] And CN^ε Terminal Definition

4.6.1 Communication Terminal Wiring Diagram



Pic 4.8 Communication Terminal Wiring

4.6.2 Communication port definition

Through the CN[∞] and CN^ε ports on the drive, the communication can be established between the drive and PC、PLC and other drives. The CN[∞] and CN^ε pins are defined as follows:

Terminal	CN [∞]	Name	CN ^ε	Name	Picture
1	NC	Null	NC	Null	
2	E·V	CAN ground	E·V	CAN ground	
3	CAN H	CAN Bus communication	CAN H	CAN Bus communication	
4	RSε∧ο -	RSε∧ο communication	RSε∧ο -	RSε∧ο communication	
5	RSε∧ο +		RSε∧ο +	RSε∧ο communication	
6	CAN L	CAN Bus	CAN L	CAN Bus	
7	GND	ε∧ο ground	GND	ε∧ο ground	
8	NC	Null	NC	Null	




- ◆ It can connect PC or the upper controllers through a special serial port cable, and it is forbidden to plug with electric.
- ◆ It is recommended to use twisted pair or shielded wire, the length of the wire is less than 7 meters.
- ◆ Multi-drives series connected, CN⁷ connect with last CN⁴, and CN⁴ connect with next CN⁷.
- ◆ When using RS⁴⁸⁵ bus communication and RS⁴⁸⁵ ground signal of the upper controller is connected to the earth (PE), please connect PE terminal of the upper controller with the drive terminal properly. In this case, it is forbidden to connect RS⁴⁸⁵ ground signal of the upper controller with the drive RS⁴⁸⁵ ground signal (GND), otherwise the driver may be damaged.

4.1.2 RS⁴⁸⁵ Communication Connection Introduction

1. Connection With RS⁴⁸⁵ of A PLC

A connection cable between the driver and the PLC is as follows:




Pic 4.1 The Communication Cable Of Servo Drive With PLC

Table 4.1 Connection Between Servo Drive And PLC Communication Cable

Drive RJ45 (A end)		PLC (B end)	
Signal Name	Pin No.	Signal Name	Pin No.
RS ⁴⁸⁵ +	4	RS ⁴⁸⁵ +	4
RS ⁴⁸⁵ -	5	RS ⁴⁸⁵ -	5
GND	7	GND	7
PE (shielded layer)	Cover	PE (shielded layer)	Cover

2. RS⁴⁸⁵ Communication Parallel Connection Of Multi Drives

When using RS⁴⁸⁵ communication network, the parallel connection of multi drives is as follows:




Pic 4.1 Parallel Cable Diagram Of Multi Drives

Table 4-3 Connection Between Multi Drives

Drive RJ45 (A end)		PLC (B end)	
Signal Name	Pin No.	Signal Name	Pin No.
RS485+	1	RS485+	1
RS485-	2	RS485-	2
GND	3	GND	3
PE (shielded layer)	Cover	PE (shielded layer)	Cover


3. RS485 Communication Grounding Precaution

When using RS485 communication, the GND terminal of the upper device is connected with the GND terminal of the servo drive as shown in the following picture:



Pic 4-11 RS485 Communication Diagram

As shown in the picture below, when using RS485 communications, the ground signal of the upper device is connected with the earth:






- ◆ PLC is built in RS485 communication terminal resistor.
- ◆ It is suggested that the shield layer should be ground at one end.
- ◆ Never connect the GND terminal of the upper device with the servo drive E+V terminal, otherwise the machine will be damaged.

4.4 Anti-jamming Countermeasures of Power Wiring


To suppress interference, please take the following measures:

- Instruction input cable length should be less than 3 meters, and encoder cable should be less than 3 meters.
- Recommend grounding cable over 3.5 mm²
- Please install a noise filter on the input side of the power cable to prevent radio frequency interference.
- To avoid electromagnetic interfering, the following methods can be used:
 - 1) Install the upper device and a noise filter near the servo drive.
 - 2) Install a surge suppressors on coils of relays, solenoids, electromagnetic contacts.
 - 3) Separate high and low voltage cables away minimum at 30 cm.
 - 4) Do not share a power supply with welding devices, discharge processing devices, etc. When there is a high frequency generator nearby, please install a noise filter on the input side of the power cable.



4.4.1 Wiring Examples Of Anti-Jamming And Ground Handling

1. Examples of anti-jamming wiring



Pic 4.12 A Example Of Anti-Jamming Wiring



- ◆ The cable of the outer box connection used for grounding should be more than 3.5 mm² of coarse wire, and braided copper cables are recommended

2. Ground handling

To avoid electromagnetic interference problems, please ground as below.

1) Grounding of servo motor housing

Please connect the grounding terminal of the servo motor with the grounding terminal PE of the servo driver and ground the PE terminal reliably to reduce the potential electromagnetic interference problem.


2) Encoder Cable Shield Grounding

Please ground both ends of shield layer of motor encoder cable.

4.7.2 How To Use A Noise Filter


In order to prevent the interference of the power cable and weaken the influence of the servo driver on other sensitive devices, please select a corresponding noise filter at the input end of power supply according to the input current. Meanwhile, please install the noise filter at the power cable of peripheral device if needed. Please observe the following precautions when installing and wiring the noise filter so as not to weaken the actual use effect of the filter.

- Please separate the input and output cables of the noise filter, and do not put both into the same pipe or tie them together.




Pic 4.13 Example Diagram Of Noise Filter Input And Output Cables

- The ground wire of the noise filter is separated from its output power cord.




Pic 4.14 Diagram Of Separating Cables Between Ground And Output Line Of Noise Filter

- Noise filters need to use a thick cable as short as possible to ground separately, and do not share a ground wire with other grounding equipment.



Pic 4.10 Single Point Grounding Diagram

- The ground handling of a noise filter installed in the control cabinet.
when the noise filter and servo driver are installed in the same control cabinet, it is recommended that the filter and servo driver are fixed on the same metal plate. To ensure the contact part is conductive and lapped well, and the metal plate is grounded.




Pic 4.11 Ground Connection Handling Of Noise Filter

Chapter 9 Running Mode And Controlling Wiring


According to the command mode and operation characteristics of a servo drive, it can be divided into three operation modes: position control operation mode, speed control operation mode and torque control operation mode.

- The position control mode usually determines the displacement of the movement by the number of pulses, and the pulse frequency of the external input determines rotation speed. Because the position mode can strictly control the position and speed, it is generally used in the positioning device. It is the most popular control mode and mainly used in robot, table placement machine, carving and milling, CNC machines and so on.
- The speed control mode controls rotation speed through the given analog quantity, the given digital quantity and the given communication speed. It is mainly used in the constant-speed applications. For example, the upper computer adopts position control mode and the servo drive adopts speed control mode in application of carving and milling machines.
- The torque control mode controls torque through the given analog quantity, the given digital quantity and the given communication speed. It is mainly used in winding and unwinding devices which have strict requirements on the force of material, such as winding device or drawing fiber equipment and other tension control applications. The setting of torque should be changed at any time according to the radius of winding to ensure that the force of material will not change with the change of winding radius.



9.1 Position Control Mode

9.1.1 Position Mode Introduction



Pic 9.1 Position Mode Diagram

The main steps for position mode are as follows:

1) Correctly connect the main circuit and the power supply, as well as the motor power cable and encoder cable. After powering on, the drive panel displays "r 0", which means that the drive power supply and encoder wiring are correct.


2) Pressing the keys for servo JOG trial operation to confirm whether the motor can run normally.

3) To connect the pulse direction input and pulse instruction input of the CN1 terminal as well as the required DI/DO signals, such as servo enable, alarm clearance, location completion signal, etc based on the figure 9.2 as a reference.

4) Then to make some setting operations. DI/DO can be set according to actual situation.

5) For servo enable, the servo motor rotation is controlled by the position instruction from the upper computer. Firstly make the motor rotate at low speed, and confirm whether the rotation direction and electronic gear ratio are normal, then make the gain adjustment.

9.1.2 Position Mode Wiring



Pic 9.2 Position Mode Wiring



- ◆ The voltage of the internal 5V power supply ranges 4.5V~4.8V, and maximum operating current 100mA. If use a external 5V power supply, please connect the external 5V+ to pin 16(COM) and the external 0V to pin 43(E0V).
- ◆ A power supply for DO output should be prepared by customers. The power ranges 0V~5V. The maximum allowable voltage is DC50V and current is 50mA.

9.1.3 Parameter Settings In Position Mode

● Gain And Smooth Filter

Parameter	Introduction	Range	Default Value
PA0	Control mode	0	0
PA1	Position Proportional Gain	1~1000	100
PA10	Position Command Smooth Filter	0~1000×0.1ms	100
PA100	Command Filter Selection	0~1	0

● Digital Input

Parameter	Introduction	Range	Default Value
PA11	Command pulses for each rotation	0~3000	1000
PA12	1 st numerator of electronic gear for position command pulse	1~32767	0
PA13	Denominator of electronic gear for position command pulse	1~32767	1000
PA14	Input mode of position command pulse	0~3	0
PA15	reverse direction of position command pulse	0~1	0
PA09	The effective edge of command pulse	0~1	0
PA17	2 nd numerator of electronic gear for position pulse	1~32767	0
PA18	3 rd numerator of electronic gear for position pulse	1~32767	0
PA19	4 th numerator of electronic gear for position pulse	1~32767	0
PA20	Effective level of command direction signal	0~1	0
PA21	Command pulse(PULS)signal filter	0~10	2
PA22	Command pulse(SIGN)signal filter	0~10	2

● Digital Output(DO)

Parameter	Introduction	Range	Default Value
PA16	Range of positioning completion	0.3... pulses	13.
PA17	Position deviation limit	0.3...×100 pulses	600
PA18	Position deviation error	0.1	0
PA19	CWL,CCWL prohibited mode	0.1	0
PA1E	Hysteresis for position completion	0.32767	60
PA1F	Range for approach positioning	0.32767	600
PA1G	Hysteresis for approach positioning	0.32767	60

● Input And Output Terminals

Parameter	Introduction	Range	Default Value
PA00	Effective level control word for input terminals	0...1111	0000
PA07	Effective level control word for output	0...1111	0000
PA08	Time constant of removing jitter for IO input terminal	1.20ms	2
P30.	Digital Input DI0 function	0.99	1
P301	Digital Input DI1 function	0.99	2
P302	Digital Input DI2 function	0.99	3
P303	Digital Input DI3 function	0.99	4
P304	Digital Input DI4 function	0.99	5
P305	Digital Input DI5 function	0.99	6
P306	Digital Input DI6 function	0.99	7
P307	Digital Input DI7 function	0.99	8
P30F	Force digital input valid0	0...00000000	00000000
P316	Force digital input valid1	0...00000000	00000000
P317	Force digital input valid2	0...00000000	00000000

P3-20	Digital Output DO1 function	0-99	18
P3-21	Digital Output DO2 function	0-99	3
P3-22	Digital Output DO3 function	0-99	5
P3-23	Digital Output DO4 function	0-99	8
P3-24	Digital Output DO5 function	0-99	6
P3-25	Digital Output DO6 function	0-99	7

● **Position Command Introduction Of Internal Position Pr Mode**

Pr position command source creates position command. Register takes the 8 groups of parameters (P2-2, P2-3)-(P2-23, P2-24). And then can choose one of 8 groups to be position command to match with 1/O(CN1, POS0-POS7 and CTRG). As below table shows:

Com mand	POS7	POS6	POS5	CTR G	Parame ter	Induction	Moving Speed Register
P1	.	.	.	↑	P2-2	circle(+/-3000)	P2-4 (V1)
					P2-3	pulse(+/-max cnt)	
P2	.	.	1	↑	P2-5	circle(+/-3000)	P2-7 (V2)
					P2-6	pulse(+/-max cnt)	
P3	.	1	.	↑	P2-8	circle(+/-3000)	P2-10 (V3)
					P2-9	pulse(+/-max cnt)	
P4	.	1	1	↑	P2-11	circle(+/-3000)	P2-13 (V4)
					P2-12	pulse(+/-max cnt)	
P5	1	.	.	↑	P2-14	circle(+/-3000)	P2-16 (V5)
					P2-15	pulse(+/-max cnt)	
P6	1	.	1	↑	P2-17	circle(+/-3000)	P2-19 (V6)
					P2-18	pulse(+/-max cnt)	
P7	1	1	.	↑	P2-20	circle(+/-3000)	P2-22 (V7)
					P2-21	pulse(+/-max cnt)	
P8	1	1	1	↑	P2-23	circle(+/-3000)	P2-25 (V8)
					P2-24	pulse(+/-max cnt)	

Note:

The state of POS \cdot - γ :

\cdot : contact break (open)

γ : contact close


CTRG \uparrow : the moment from open (\cdot) to close (γ)

Max: the command pulses of the motor in one revolution

Absolute position register is broadly applied. User can easily complete periodicity actions by the above table. For example, the position command

P γ = γ \cdot revolution, P γ = γ \cdot revolution. P γ should be followed by P γ .


Differences between P γ and P γ as below:



PROLINECNC

9.2 Speed Control Mode Wiring

9.2.1 Introduction



Pic 9.2 Speed Control Mode

The main steps to use the speed control mode are as follows:

1) correctly connect the servo main circuit and the power supply of the controller, as well as the motor cable and encoder cable. The servo panel displays "r 0" after powering on which means that the servo power supply and encoder connection are correct.


2) Operate the servo JOG trial running mode through the panel keys to confirm whether the motor can run normally.

3) To connect the required DI/DO signals in CN1 terminal, such as servo enable, alarm clearance, positioning completion signal, etc referring figure 9.4.

4) To operate speed mode related setting. DI/DO are used to set according to your application.

5) To make the servo enabled and the servo motor rotation is controlled by the position instruction issued by the upper computer. First make the motor rotate at low speed, and confirm whether the rotation direction and electronic gear ratio are normal, then make the gain adjustment.

9.2.2 Speed Mode Wiring




Pic 9.2.2 Speed Mode Wiring

5.2.3 Parameter Settings In Speed Mode

Parameter	Introduction	Range	Default Value
PA0	Control Mode	1	0
PA1	Speed Proportional Gain	0~2000Hz	100
PA2	Speed Integral Constant	1~1000ms	70
PA3	Internal And External Speed Instruction Selection	0~0	0
PA4	Internal Speed 1	-7000~7000r/min	100
PA5	Internal Speed 2	-7000~7000r/min	000
PA6	Internal Speed 3	-7000~7000r/min	1000
PA7	Internal Speed 4	-7000~7000r/min	2000
PA8	Arrival Speed	0~3000r/min	3000
PA9	Acceleration Time Constant	1~10000ms	100
PA10	Deceleration Time Constant	1~10000ms	100
PA11	S Type Acceleration And Deceleration Time Constant	0~1000ms	0
PA12	Gain Of Analog Speed Command	10~3000r/min/v	300
PA13	Direction Of Analog Speed Command	0~1	0
PA14	Zero Offset Compensation Of Analog Speed Command	-0.000~0.000	0
PA15	Filter Of Analog Speed Command	1~300Hz	300
PA16	Zero-speed Detection Point	0~1000r/min	10
PA17	The Setting Value For Speed Consistent	0~1000r/min	10
PA18	Hysteresis Of Arrival Speed	0~0.000r/min	30
PA19	Polarity Of Arrival Speed	0~1	0
PA20	Hysteresis For Zero Speed Detection	0~1000r/min	0

2.3 Torque Control Mode

2.3.1 Introduction




Pic 2.3 Torque Control Mode

The main steps to use the speed control mode are as follows:

- 1) Correctly connect the servo main circuit and the power supply of the controller, as well as the motor cable and encoder cable. The servo panel displays "r 0" after powering on which means that the servo power supply and encoder connection are correct.
- 2) Operate the servo JOG trial running mode through the panel keys to confirm whether the motor can run normally.
- 3) To connect the required DI/DO signals in CN1 terminal, such as servo enable, alarm clearance, positioning completion signal, etc referring figure 2.4.
- 4) To operate torque mode related setting. DI/DO are used to set according to your application.
- 5) To make the servo enabled and the servo motor rotation is controlled by the position instruction issued by the upper computer. First make the motor rotate at low speed, and confirm whether the rotation direction and electronic gear ratio are normal, then make the gain adjustment.

5.3.2 Speed Mode Wiring



5.3.3 Parameter Settings In Torque Mode

Parameter	Introduction	Range	Default Value
PA01	Control mode	2	0
PA09	Gain of analog torque command	Set by yourself	30
PA32	Selection for internal and external torque command	0-2	0
PA33	Direction of analog torque command	0	0
PA39	Zero offset compensation of analog torque command	0	0
PA00	Speed limit in torque control mode	Set by yourself	Rated Speed
PA61	Internal torque 1	-300-300	0
PA60	Internal torque 2	-300-300	0
PA66	Internal torque 3	-300-300	0
PA67	Internal torque 4	-300-300	0
PA83	Inhibition method	0-1	0
PA89	Arrival torque	-300%-300%	100
PA90	Hysteresis of arrival torque	0%-300%	0
PA91	Polarity of arrival torque	0-1	0

PROLINECNC

9.4 Origin Regression Function And Relevant Parameters Introduction

9.4.1 Relevant Parameter Settings

Parameter	Introduction	Value	Default Value
P9-32	Origin detector type or search direction setting	0-0	0
P9-33	Set the model of short distance movement to the origin	0-2	0
P9-34	Origin trigger start mode	0-2	0
P9-35	Origin stop mode setting	0-1	0
P9-36	The first stage of high speed origin regression speed setting	1-2000 r/min	1000
P9-37	The second stage of low speed origin regression speed setting	1-500 r/min	50
P9-38	Cycles of origin regression offset	+/-3000	0
P9-39	Pulses of origin regression offset	+/-max cnt	0

PROLINECNC

9.4.2 Origin Regression Mode Introduction(Must be in internal position mode)

A. Origin trigger start mode(P4-34)

The origin trigger start mode is divided into two kinds of origin regression function. One is automatic performing and another is contacting trigger. Details as below:

P4-34=0: close origin regression function. When set P4-34=0, the origin regression function can not work no matter what its setting value is.

P4-34=1: when the power is on, it will execute origin regression automatically. The function is available one when the power supply and servo on, which means it is unnecessary to repeat the operation when the servo works. It can save one input contact used to perform the origin regression.

P4-34=2: It triggers origin regression function through the input contact SHOM.

One of registers which are input pin function planning register must be set to SHOM trigger input function. The SHOM contact can be triggered at any time during the servo working and the function of origin regression can be performed.

B. Origin trigger start mode(P4-35)

The origin detector can use either the left limit switch or the right limit switch as the reference point for the origin. Or it can use extra detectors such as near type or light-gate type switch) as the reference. The Z pulse can be also set as a reference point when the servo motor moves in only one revolution.

P4-35=0: CW direction finds the origin and use CCWL limit as a rough reference point. When completing origin positioning, CCWL is limit input function. The subsequent retrigger will occur limit warning. When using limit input point as a rough reference point, recommended to set Z pulse(P4-36) as the precise mechanical origin.

P4-35=1: CCW direction finds the origin point and use CWL limit as a rough reference point. CWL is limit input function. The subsequent retrigger will occur limit warning. When using limit input point as a rough reference point, recommended to set Z pulse(P4-36) as the precise mechanical origin.

P4-35=2: CW direction finds the origin point and use ORGP(external detector input point) as the origin point reference. Then Z pulse of return search(P4-37=0) or do not return search(P4-37=1) can be set as the precise mechanical origin point. If do not use Z pulse as the mechanical origin point, the positive edge of ORGP can be also set as the mechanical origin point(P4-37=2).

$P\dot{\iota}-\text{r}\text{r}=3$: CCW direction finds the origin point and use ORGP(external detector input point) as the origin point reference. Then Z pulse of return search($P\dot{\iota}-\text{r}\text{r}=0$) or do not return search($P\dot{\iota}-\text{r}\text{r}=1$) can be set as the precise mechanical origin point. If do not use Z pulse as the mechanical origin point, the positive edge of ORGP can be also set as the mechanical origin point($P\dot{\iota}-\text{r}\text{r}=2$).

$P\dot{\iota}-\text{r}\text{r}=4$: CW direction finds Z pulse origin point directly. This function is usually used for servo motor motion control in only one rotation range and now any detector switches are unnecessary connected.

$P\dot{\iota}-\text{r}\text{r}=0$: CCW direction finds Z pulse origin point directly. This function is usually used for servo motor motion control in only one rotation range and now any detector switches are unnecessary connected.

C. Movement mode setting of short distance to the origin ($P\dot{\iota}-\text{r}\text{r}$)

$P\dot{\iota}-\text{r}\text{r}=0$: after the origin point has been found, the servo motor returns at the second stage of speed to search the nearest Z pulse as the mechanical origin point.

$P\dot{\iota}-\text{r}\text{r}=1$: after the origin point has been found, the servo motor changes to the second stage of speed to keep searching the nearest Z pulse as the mechanical origin.

$P\dot{\iota}-\text{r}\text{r}=2$: the rising edge of ORGP which was found is set as the mechanical origin point and stops according to deceleration, which is applied to $P\dot{\iota}-\text{r}\text{r}=2$ or 3 . Or when found Z pulse, it stops according to deceleration, which is applied to $P\dot{\iota}-\text{r}\text{r}=4$ or 0 . And the value of $P\dot{\iota}-\text{r}\text{r}$ for detecting origin detection is only applicable to 2 or 3 . Under Z pulse origin point detecting, $P\dot{\iota}-\text{r}\text{r}$ is only applicable to 4 or Z pulse.

D. The mode setting of origin point stops ($P\dot{\iota}-\text{r}\text{r}$)

$P\dot{\iota}-\text{r}\text{r}=0$: after the origin detection has been completed, the motor slows down and is pulled back to the origin point. The motor slows down and stops when it gets the signal of origin detection at the second stage of speed. Then it moves back to the mechanical original position.

$P\dot{\iota}-\text{r}\text{r}=1$: after the origin detection has been completed, the motor decelerates and stops in the forward direction. The motor slows down and stops when it get the signal of origin detection at the second stage of speed. Then position overrun is no longer modified and the mechanical original position would not change even there are different position overruns.

9.1 Pre-operational Inspection

Before connecting the load, the motor should be run for checking.

- Check and ensure before running:

- 1) There is no obvious damage to the appearance of the servo drive. 2) Wiring terminals are insulated.

- 3) There are no conductive objects, such as screws or metal plates, combustible objects inside the drive, and no conductive objects at the connection port.

- 4) Do not place the servo drive or a external brake resistor on combustibles.

- 5) Please wire correctly.

- Driver power supply, auxiliary power supply, grounding end and other wiring should be wired correctly. Each control signal cable connection should be correct. Each limit switch, protection signal have been correctly connected.

- 1) Enabled switch in OFF state.

- 2) Cut off power supply circuit and stop alarm circuit to maintain access ope.

- 3) Servo driver applied voltage reference should be correct.

- Power the servo drive when the controller does not send a running command signal. Check and guarantee:

- 1) The servo motor can turn normally without vibration or operating sound phenomenon.

- 2) All parameters are set correctly, according to different mechanical characteristics and please do not over-set extreme parameters.

- 3) Bus voltage indicator lamp and digital tube display are normal.




PROLINECNC

Chapter 1 Operation And Display

1.1 Drive Panel Introduction

1.1.1 Front Panel

The panel consists of 5 digital LED and 4 buttons including ▲、▼、◀、SET to display all system status and set parameters. The operation is hierarchical. ▶ button indicates “back” and SET button indicates “forward” while it also has the meaning of “Enter” and ▶ button also has the meaning of “Cancel” and “Exit”. ▲ button indicates “Increasing ” and ▼ button indicates “decreasing”. If you press the ▲ button or ▼ button and maintain it, you would get a duplicate result and stay longer, the repetition rate is higher.




Pic 1.1 Drive Panel Display

1.1.2 Front Keys Introduction

Key	Name	Function
▲	Increasing	Increase sequence number or value;Press down and hold to repeat increasing.
▼	Reducing	Decrease sequence number or value;Press down and hold to repeat decreasing.
▶	Exit	Menu exit; Cancel the operation
SET	Confirm	Menu entered; Confirm the operation

٦.٢ Main Menu

The first layer is the main menu and has ٨ operating modes in total. Press ▲ or ▼ button to change the operation mode. Then press SET button to enter into the second layer and executes a concrete operation. Press ◀ button returns to the main menu from the second layer.






Pic ٦.٢ Main Menu

٦.٢ Steps To Set Parameters

Select “PA-” and press SET button to enter the status of parameter setting mode. And use ▲ or ▼ to choose parameters and then press SET button to display the parameter value. You can modify the value with ▲ or ▼ key. Press ▲ key or ▼ key once, the parameter value increases or decreases by ١. Pressing and holding ▲ or ▼ key can make the value increased or decreased continuously. After modifying the value of the parameter, please press SET button and when the LED flashes two times, it means the setting is completed. Finally please recharge, then the new parameter is effective.

٦.٤ Status Monitoring

In the first layer, select “DP--” and press SET button to enter into monitoring mode. There are ٢٢ displays in total. Users select the desired display mode with  or  key, and then press SET button to enter into the specific states.

Status	Operation	Example	Definition
P-SPd		r 1000	Motor speed: ١٠٠٠ r / min
P-PoS		04580	The current position: ١٢٤٥٨٠
P-PoS.		P. 12	
P-CPo		C4581	Position command: ١٢٤٥٨١
P-CPo.		C. 12	
P-EPo		E 4	Position deviation: ٤ pulses
P-EPo.		E. 0	
P-trq		t 0.70	Motor torque ٧٠%
P- I		I 2.3	Motor current ٢,٣A
P-Cnt		Cnt 0	Control mode ٠: position control
P- CS		r. 500	In speed mode, analog input speed: ٥٠٠ r/min
P- Ct		t 0.50	In torque mode, analog input torque: ٥٠%
P-APo		A3265	Absolute rotor position: ٣٢٦٥
P-APo.		A. 0	
P- In		n 1111	Input terminal
P-oUt		oUt,111	Output terminal
P-UdC		UC336	Line voltage: ٣٣٦V
P-Err		Err 4	No. ٤ alarm


Status	Operation	Example	Definition
P- rL		rL-on	Relay open
		rL-of	Relay Uncharged
		rL-Er	Relay alarming
P- rn		rn-on	Main circuit working normally
		rn-of	Main circuit Uncharged
		rn-CH	Main circuit not enabled
		rn-Er	Main circuit alarming
P- US		U-on	Line voltage normally
		U-LoU	Line voltage too low
		U-Err	Line voltage alarming
P- AS		43210	Absolute motor position ^{٨٧٦٥٤٣٢١٠} .
P- AS.		A.8765	

6.5 Analog Quantity Zeroing Adjustment

Using this function,the servo drive can check analog zero offset automatically and write the offset value into parameter PA⁷⁹ or PA⁸⁰. The operation has saved offset parameter to EEPROM, so it is unnecessary to write parameters again.

Firstly choose analog zero adjustment mode “A-A.” and press SET key to enter into the second layer. Select speed analog zeroing “A-SPd” or torque analog zeroing “A-Trq” and then keep pressing SET key for more than 3s. When it displays “done”, the activation is completed.

6.6 Encoder Selection

Select "F-res" to reset the encoder and make the encoder multi-circle information zeroing. By setting P³⁻³⁶ parameter , the single-circle information can be cleared to achieve the purpose of setting the original point. Select" F-clr" to clear the encoder NO. 03 alarm caused by battery power down. After long press the SET key for more than 3 seconds and show "done", the operation is activate. After that, press the  key to return to the upper menu.

6.2 How To Reset Default Parameters

To recover default parameters when:







- The parameters are scrambled and the system can not work properly.


The steps to recover default parameters as follow:

1. Please connect the motor with the driver and power on. The driver will automatically read the motor parameters and match the motor model.

2. Set password (PA*) to 380.

3. Do the followings:

Press the  key to return to the main menu and to select "PA-" with  or  key. Press the **SET** key to enter into the second layer and press the  or  key to make PA=*. Then press the **SET** key to enter into the third layer and set PA*=380, pressing the **SET** key to save it. Next, press the  key to return to the "PA-" and set the PA*=DEF-. Long press the **SET** key for 5 seconds and after the LED indicator lights flicker several times, the operation is completed. Finally, it will work after repower on.



Chapter Ⅴ Parameters

Ⅴ.1 PA Group

No.	Name	Function	Rang	Default Value
0	Password	1. User code: 310. 2. Motor model code: 380.	0-9999	310
1	Motor selection	The parameter is read-only and can not be modified. The driver automatically identifies the motor model.	0-8	Table Ⅴ-1
2	Software version	The software version can be read but can't be modified.		

Table Ⅴ-1

Drive	0-4	5-9
Motor	0-013	8-013
	0-033	8-023
	6-063	8-033
	6-0133	--
	6-0193	--
	8-0133	--

PROLINECNC

No.	Name	Function	Rang	Default Value
3	Initial display status	<p>0: Display motor speed.</p> <p>1: Display the current position is 0-bit low.</p> <p>2: Display the current position is 0-bit high.</p> <p>3: Display position command.</p> <p>(command pulse accumulation) is 0-bit low.</p> <p>4: Display position command.</p> <p>(command pulse accumulation) is 0-bit high.</p> <p>5: Display position deviation is 0-bit low.</p> <p>6: Display position deviation is 0-bit high.</p> <p>7: Display motor torque.</p> <p>8: Display motor current.</p> <p>9: Display control mode.</p> <p>10: Display temperature.</p> <p>11: Display speed command..</p> <p>12: Display torque command.</p> <p>13: Display absolute position of the rotor in a roll is 0-bit low.</p> <p>14: Display absolute position of the rotor in a roll is 0-bit high.</p> <p>15: Display input terminal state.</p> <p>16: Display output terminal state.</p> <p>17: Display encoder input signal.</p> <p>18: Display voltage value of main line of main circuit.</p> <p>19: Display alarming code.</p> <p>20: Display logic chip version number.</p> <p>21: Display the actuation state of the relay.</p> <p>22: Display external voltage state.</p> <p>23: Display external voltage state.</p> <p>24: Absolute position 0-bit low.</p> <p>25: Absolute position 0-bit high.</p>	0-25	.

No.	Name	Function	Rang	Default Value
Ⅴ	Control mode selection	To set control method: Ⅰ: position control mode Ⅱ: speed control mode Ⅲ: torque control mode Ⅳ: position + speed control mode Ⅴ: position + torque control mode Ⅵ: speed + torque control mode Ⅶ: encoder zeroing mode	0-7	0
Ⅵ	Proportional gain of speed loop	Ⅰ. Set the proportional gain of speed loop. Ⅱ. The value is bigger, the gain is higher and rigidity is stronger. The parameter value is set according to your exact servo driving system model and the load. Generally, the greater the load inertia, the bigger the value. Ⅲ. Please set a little high value if the system condition does not generate oscillation.	0-2000 Hz	100
Ⅶ	Speed integral constant	Ⅰ. To set the integral time constant of the speed loop regulator. Ⅱ. The value is smaller, the integral speed is faster and the servo rigidity is stronger. But if it is too small, it will happen over controlling.	1-1000 ms	70
Ⅷ	Torque filter	Ⅰ. To set the characters of torque command filter. Ⅱ. To suppress resonance generated by torque. Ⅲ. The value is smaller, the cut-off frequency is lower and vibration with noise generated by the motor is less. If the load inertia is great, reducing the setting value is recommended. If the value is too small, it would lead to low response, which would result in shaking. Ⅳ. The value is bigger, the cut-off frequency is higher and the response frequency is quicker. If	20-500 %	100


		you need higher torque response frequency, it is recommended to increase the setting value.		
8	Speed detection filter	<p>1. To set the characters of speed detection filter.</p> <p>2. The value is smaller, the cut-off frequency is lower and noise from the motor is smaller. If the load inertia is great, reducing the setting value is recommended. If the value is too small, it would lead to low response, which would result in shaking.</p> <p>3. The value is bigger, the cut-off frequency is higher and the response frequency is quicker. If you need higher torque response frequency, it is recommended to increase the setting value.</p>	0.000%	100
9	Proportional gain of position loop	<p>1. To set the proportional gain of position loop .</p> <p>2. The value is bigger, the gain is higher and its rigidity is stronger. So the position lag is smaller under the same frequency command pulse condition. But if it is too big, it will happen oscillation.</p> <p>3. The parameter value is set according to your exact servo driving system model and the load.</p>	1.100	80
10	Number of pulses output for each motor revolution	To set the number of pulses output by the encoder AB phase for each motor revolution.	0.2000	1000
11	Command pulses of each motor revolution	<p>1. To set command pulses of each motor revolution.</p> <p>2. When it is set to 0, PA12 (numerator of electronic gear for position command pulses), PA13 (denominator of electronic gear for position command pulses) are valid.</p>	0.3000	1000

12	1st numerator of electronic gear for position command pulse	<p>1. Set the electric gear ratio for position command pulse.</p> <p>2. In position control mode, it is convenient to match all kinds of pulse source through set the parameter PA12 and PA13, which helps to reach ideal control resolution (angle/pulse).</p> <p>3. $P \times G = N \times C \times \xi$</p> <p>P: pulses of input command; G: electric gear ratio; N: numbers of motor rotation; C: solutions of photoelectric encoder in per rotation, the default value is 2000.</p> <p>4. For example, input command pulse P is 1000, servo motor rotate a roll:</p> <p>$G = (N \times C \times \xi) / P = (1 \times 2000 \times \xi) / 1000 = 0/3$, So PA12 should be set to 0, PA13 should be set to 3.</p> <p>0. The numerator of electronic gear for command pulse is decided by Gear1 and Gear2. The denominator is decided by PA13. The details as following:</p> <table><tr><th colspan="2">Signal</th><th rowspan="2">Denominator</th></tr><tr><th>Gear 2</th><th>Gear 1</th></tr><tr><td>0</td><td>0</td><td>1st Numerator (PA12)</td></tr><tr><td>0</td><td>1</td><td>2nd Numerator (PA14)</td></tr><tr><td>1</td><td>0</td><td>3rd Numerator (PA15)</td></tr><tr><td>1</td><td>1</td><td>4th Numerator (PA16)</td></tr></table> <p>Remark: 0=OFF, 1=ON.</p>	Signal		Denominator	Gear 2	Gear 1	0	0	1st Numerator (PA12)	0	1	2nd Numerator (PA14)	1	0	3rd Numerator (PA15)	1	1	4th Numerator (PA16)	1-32767	.
Signal		Denominator																			
Gear 2	Gear 1																				
0	0	1st Numerator (PA12)																			
0	1	2nd Numerator (PA14)																			
1	0	3rd Numerator (PA15)																			
1	1	4th Numerator (PA16)																			
13	Denominator of position command pulse	Refers to parameter PA12.	1-32767	10000																	

No.	Name	Function	Rang	Default Value
14	Input mode of position command pulse	1. Set the input mode of position command pulse. 2. To set one of 4 input modes: 0: Pulse+Direction. 1: CCW pulse/CW pulse. 2: phase A and phase B orthogonal input. 3: Internal position input. Remark: CCW: observe from the motor axial direction. It defines CCW in counter clock wise and CW in clock wise.	0~3	0
15	Direction of command pulses	0: Normal direction. 1: Reverse position command pulse.	0~1	0
16	The rang of positioning completion	1. Setting the pulse range of positioning completion in position control mode. 2. The drive judges whether it has finished positioning completion based on this parameter. When the rest pulses in position deviation counter are less than or equal with the setting value, the COIN (positioning completion) of digital output(DO) is ON, or else OFF	0~30000 pulses	130
17	Detection of over-travel range	1. Set alarming detection range of over travel.. 2. In position control mode, if the value in position deviation counter is over than the setting value, the drive will alarm.	0~30000×100 pulses	6000
18	Invalid over-travel error	Set to: 0: The alarming detection of over travel is valid. 1: The alarming detection of over travel is invalid, and it stops detecting the error .	0~1	0

No.	Name	Function	Rang	Default Value
19	Position command smooth filter	<p>1. To filter the instruction pulse with exponential acceleration and deceleration, and the value represents the time constant.</p> <p>2. The filter does not lose input pulses, but would occur command delay .</p> <p>3. The filter applies in</p> <p>(1. PC controller without acceleration and deceleration function.</p> <p>(2. The electronic gear frequency is a little big(>10).</p> <p>(3. The command frequency is a little low.</p> <p>(4. When the motor runs, there are step jumps and unsmooth.</p> <p>5. When set to value "0", the filter does not work.</p>	0.1~1000ms	100
20	Invalid input of drive inhibition	<p>To set:</p> <p>0: CCW drive inhibition or CW drive inhibition is effective. If the switch of CCW drive inhibition is ON, CCW drive is permitted. If the switch of CCW drive inhibition is OFF, CCW torque keeps 0. The same as CW drive inhibition. If both CCW and CW drive inhibition are OFF, it will come to error alarms of drive inhibition input.</p> <p>1: Cancel CCW or CW drive inhibition. No matter what state of the switch of CCW or CW drive inhibition is, CCW or CW drive is allowed. Meanwhile, if the switches of CCW and CW drive inhibition are OFF, it will still not alarm..</p>	0~1	1
21	JOG speed	Set the running speed of JOG operating.	0.1~1000r/min	100

No.	Name	Function	Rang	Default Value																																		
٢٢	The source of speed command	<p>In speed control mode, it sets the source of speed command. It means:</p> <p>•: Analog Terminal AS+,AS- input analog speed command.</p> <p>١:Internal speed command is decided by SP١ and SP٢ of digital input(DI):</p> <table><tr><th colspan="2">DI Signal</th><th rowspan="2">Speed Command</th></tr><tr><th>SP٢</th><th>SP١</th></tr><tr><td>•</td><td>•</td><td>Internal Speed١(PA٢٤)</td></tr><tr><td>•</td><td>١</td><td>Internal Speed٢(PA٢٥)</td></tr><tr><td>١</td><td>•</td><td>Internal Speed٢(PA٢٦)</td></tr><tr><td>١</td><td>١</td><td>Internal Speed٢(PA٢٧)</td></tr></table> <p>Note: ١=ON, •=OFF.</p> <p>٢: Analog speed command+internal speed command:</p> <table><tr><th colspan="2">DI Signal</th><th rowspan="2">Speed Command</th></tr><tr><th>SP٢</th><th>SP١</th></tr><tr><td>•</td><td>•</td><td>Analog Speed Command</td></tr><tr><td>•</td><td>١</td><td>Internal Speed٢(PA٢٥)</td></tr><tr><td>١</td><td>•</td><td>Internal Speed٢(PA٢٦)</td></tr><tr><td>١</td><td>١</td><td>Internal Speed٢(PA٢٧)</td></tr></table> <p>٣: JOG speed command, if carries out JOG operation,it is needed to set.</p> <p>٤: Keyboard speed command, if carries out Sr operation,it needs to set the parameter.</p> <p>٥:IO terminal controls JOG operation.</p>	DI Signal		Speed Command	SP٢	SP١	•	•	Internal Speed١(PA٢٤)	•	١	Internal Speed٢(PA٢٥)	١	•	Internal Speed٢(PA٢٦)	١	١	Internal Speed٢(PA٢٧)	DI Signal		Speed Command	SP٢	SP١	•	•	Analog Speed Command	•	١	Internal Speed٢(PA٢٥)	١	•	Internal Speed٢(PA٢٦)	١	١	Internal Speed٢(PA٢٧)	٠-٥	•
DI Signal		Speed Command																																				
SP٢	SP١																																					
•	•	Internal Speed١(PA٢٤)																																				
•	١	Internal Speed٢(PA٢٥)																																				
١	•	Internal Speed٢(PA٢٦)																																				
١	١	Internal Speed٢(PA٢٧)																																				
DI Signal		Speed Command																																				
SP٢	SP١																																					
•	•	Analog Speed Command																																				
•	١	Internal Speed٢(PA٢٥)																																				
١	•	Internal Speed٢(PA٢٦)																																				
١	١	Internal Speed٢(PA٢٧)																																				
٢٣	Highest speed limit	<p>Set the highest speed of the ac motor.</p> <p>١.It doesn't matter with rotating direction.</p> <p>٢.If the setting value is beyond of rated speed, the real highest speed is set as the rated speed.</p>	٠-٦٠٠٠r/m in	٥٠٠٠																																		

No.	Name	Function	Rang	Default Value											
24	Internal speed selection 1	1. Set the internal speed 1. 2. In speed control mode(PA24=0), when SC1 and SC2 are OFF, internal speed 1 is the speed command.	-1000- 1000 r/min	100											
25	Internal speed selection 2	1. Set the internal speed 2. 2. In speed control mode(PA25=0), when SC1 is ON,while SC2 is OFF, internal speed 2 is the speed command.	-1000- 1000 r/min	500											
26	Internal speed selection 3	1. Set the internal speed 3. 2. In speed control mode(PA26=0), when SC1 is OFF,while SC2 is ON, internal speed 3 is the speed command.	-1000- 1000 r/min	1000											
27	Internal speed selection 4	1. Set the internal speed 4. 2. In speed control mode(PA27=0), when SC1 and SC2 are ON, internal speed 4 is the speed command.	-1000- 1000 r/min	2000											
28	Speed arrival	1. Set the detection timing of the speed arrival output. When the servomotor speed surpasses this parameter, the digital output (DO) ASP (arrival speed) is ON, otherwise is OFF. 2. The comparator has hysteresis function set by PA28. Detection is associated with 10 r/min hysteresis.  3. It also has the polarity setting function: <table><tr><th>PA28</th><th>PA29</th><th>Comparator</th></tr><tr><td>0</td><td>> 0</td><td>No direction for speed</td></tr><tr><td rowspan="2">1</td><td>> 0</td><td>Only detect CCW speed</td></tr><tr><td>< 0</td><td>Only detect CW speed</td></tr></table>	PA28	PA29	Comparator	0	> 0	No direction for speed	1	> 0	Only detect CCW speed	< 0	Only detect CW speed	-1000- 1000 r/min	3000
PA28	PA29	Comparator													
0	> 0	No direction for speed													
1	> 0	Only detect CCW speed													
	< 0	Only detect CW speed													

29	Gain of analog quantity torque command	<p>1. Set the proportion for input voltage of analog torque and the actual motor running torque.</p> <p>2. The setting value unit is $\frac{V}{V} \%$.</p> <p>3. The default value is 30, corresponding to $\frac{3V}{100V} \%$, while it means if the input voltage is 3V, it would generate 100% rated torque.</p>	<p>10-100</p> <p>(0, 1V/100%)</p>	30																	
30	The alarm value of torque overload	<p>1. The value is the percentage of rated torque. The limit is independent to direction and CW or CCW direction is protected.</p> <p>2. When $PA31 > 9$, motor torque $> PA30$ and duration $> PA31$, the drive alarms and the code is Err-39. The motor stops working. It must repower on after clearing errors.</p>	1-300	300																	
31	The detection time for torque overload	<p>1. The detection time for torque overload, unit:ms.</p> <p>Detection time=$PA31 \times 0.1$.</p> <p>2. When set to 0~9, the function of torque overload alarming is prohibited. Generally, the value is set as 0.</p>	0-32767	0																	
32	The source of torque command	<p>In torque control mode, it sets the source of torque command. It means:</p> <p>0: Analog torque command, it inputs by analog terminal AS+ and AS-.</p> <p>1: Internal torque command, it is decided by TRO1 and TRQ2 of digital input(DI):</p> <table><tr><th colspan="2">DI Signal</th><th rowspan="2">Torque Command</th></tr><tr><th>TRQ2</th><th>TRQ1</th></tr><tr><td>0</td><td>0</td><td>Internal Torque1(PA64)</td></tr><tr><td>0</td><td>1</td><td>Internal Torque2(PA65)</td></tr><tr><td>1</td><td>0</td><td>Internal Torque3(PA66)</td></tr><tr><td>1</td><td>1</td><td>Internal Torque4(PA67)</td></tr></table> <p>Note: 0=OFF, 1=ON</p>	DI Signal		Torque Command	TRQ2	TRQ1	0	0	Internal Torque1(PA64)	0	1	Internal Torque2(PA65)	1	0	Internal Torque3(PA66)	1	1	Internal Torque4(PA67)	0-1	0
DI Signal		Torque Command																			
TRQ2	TRQ1																				
0	0	Internal Torque1(PA64)																			
0	1	Internal Torque2(PA65)																			
1	0	Internal Torque3(PA66)																			
1	1	Internal Torque4(PA67)																			

		Ⅴ:Analog torque command+internal torque command:																				
		<table><tr><th colspan="2">DI Signal</th><th rowspan="2">Torque Command</th></tr><tr><th>TRQⅤ</th><th>TRQⅥ</th></tr><tr><td>•</td><td>•</td><td>Analog Torque Command</td></tr><tr><td>•</td><td>Ⅰ</td><td>Internal TorqueⅤ(PAⅥ○)</td></tr><tr><td>Ⅰ</td><td>•</td><td>Internal TorqueⅥ(PAⅥⅠ)</td></tr><tr><td>Ⅰ</td><td>Ⅰ</td><td>Internal TorqueⅦ(PAⅥⅡ)</td></tr></table>		DI Signal		Torque Command	TRQⅤ	TRQⅥ	•	•	Analog Torque Command	•	Ⅰ	Internal TorqueⅤ(PAⅥ○)	Ⅰ	•	Internal TorqueⅥ(PAⅥⅠ)	Ⅰ	Ⅰ	Internal TorqueⅦ(PAⅥⅡ)		
DI Signal		Torque Command																				
TRQⅤ	TRQⅥ																					
•	•	Analog Torque Command																				
•	Ⅰ	Internal TorqueⅤ(PAⅥ○)																				
Ⅰ	•	Internal TorqueⅥ(PAⅥⅠ)																				
Ⅰ	Ⅰ	Internal TorqueⅦ(PAⅥⅡ)																				
ⅢⅢ	The input direction of analog torque command	Reverse the input polarity of analog torque.		•-Ⅰ	•																	
ⅢⅣ	Internal CCW torque limit	Ⅰ.The setting value is the percentage of rated torque.For example,it is set to Ⅴ times of the rated torque, the value is Ⅴ••. Ⅱ. At any time, this restriction is valid. Ⅲ. If the setting value is over than the max overload capacity, the actual torque limit is the max overload capacity that is permitted.		•-Ⅲ••%	Ⅲ••																	
Ⅲ○	Internal CW torque limit	Ⅰ.The setting value is the percentage of rated torque.For example,it is set to Ⅴ times of the rated torque, the value is Ⅴ••. Ⅱ. At any time, this restriction is valid. Ⅲ. If the setting value is over than the max overload capacity, the actual torque limit is the max overload capacity that is permitted.		-Ⅲ••-•%	-Ⅲ••																	
ⅢⅠ	External CCW torque limit	Ⅰ. The setting value is the percentage of rated torque, for example, it is set to Ⅰ time of rated torque, the value is Ⅰ••. Ⅱ.Only when the input terminal(FIL) of CCW torque limit is ON is it valid. Ⅲ.When the limit is valid, the actual torque limit is		•-Ⅲ••%	Ⅰ••																	

		the Minimum value of max overload capacity ,internal CCW torque limit and external CCW torque limit.		
37	External CW torque limit	<p>Set external torque limit of the motor CW direction.</p> <p>1. The setting value is the percentage of rated torque, for example, it is set to 1 time of rated torque, the value is -100.</p> <p>2. Only when the input terminal(RIL) of CW torque limit is ON is it valid.</p> <p>3. When the limit is valid, the actual torque limit is the Minimum value of max overload capacity ,internal CCW torque limit and external CCW torque limit.</p>	-300~0%	-100
38	Temperature alarm	Set drive temperature up to max limitation.	200~1300	
39	Zero offset compensation of analog torque command	Make an offset adjustment for analog torque command with this parameter.	-2000~2000	0
40	Acceleration time constant	<p>The value means the motor of acceleration time from 0r/min to 1000r/min.</p> <p>1. Linear acceleration and deceleration characteristics.</p> <p>2. It only applies in speed control mode and internal position control mode, and other modes are invalid..</p>	1~10000ms	100
41	Deceleration time constant	<p>The value means the deceleration time of the motor from 1000r/min to 0r/min.</p> <p>1. Linear acceleration and deceleration characteristics.</p> <p>2. It only applies in speed control mode and internal position control mode, while other modes are invalid.</p> <p>3. This parameter should be set to 0 if the drive is used in combination with an external position loop.</p>		

No.	Name	Function	Rang	Default Value
ε2	S type acceleration and deceleration time constant	It makes the motor start and stop working stably and sets a part of time of S type acceleration and deceleration curve.	0.1~100ms	1
ε3	Gain of analog speed command	Set the proportion for analog speed input voltage and actual motor running speed.	1~3000 r/min/v	300
ε4	Direction of analog speed command	Reverse the input polarity of analog speed. 1. Set to 0 and analog speed command is positive, the speed direction is CCW. 2. Set to 1 and analog speed command is positive, the speed direction is CW.	0~1	0
ε5	Zero offset compensation of analog speed command	Make an offset adjustment for analog speed command with this parameter.	-5000~ 5000	0
ε6	Filter of analog speed command	1. The input low pass filter of analog speed 2. The setting value is bigger, the response frequency is quicker to speed input analog quantity and the influence of signal noise is louder.	1~1000 Hz	300
ε7	The setting of mechanical brake when the motor stops	1. It defines the delay time from BRK=ON and BRK=OFF to the motor current cutting off when the motor stops rotating. 2. To avoid a small displacement or working drop of the motor, the parameter should not be less than the delay time of mechanical braking.	0.2~1000ms	1

No.	Name	Function	Rang	Default Value
٤٨	The setting of mechanical brake when the motor rotates	١. It defines the delay time from the motor current cutting off to BRK=ON and BRK=OFF when the motor rotates. ٢. To avoid a damage to the brake, the parameter makes the motor slow down and then makes the mechanical brake work. ٣. The actual action time is the time it takes to drop from PA٤٨ or current motor speed to PA٤٩, and taking the minimum value.	٠.٢٠٠×١٠ms	٠.٠
٤٩	The working speed of the mechanical brake when the motor rotates	١. It defines the speed value from motor current cut-off to mechanical brake action (output terminal BRK from ON to OFF) during motor working. ٢. The actual action time is the time it takes to drop from PA٤٨ or current motor speed to PA٤٩, and taking the minimum value.	٠.٣٠٠٠ r/min	١٠٠
٥٠	Speed limit in torque control mode	١: In torque control mode, the motor running speed is limited in the range of this parameter. ٢: It can prevent over speed in light load.	٠.٥٠٠٠ r/min	٣٠٠٠
٥٣	Servo force enable	To set : ٠: The enable signal is controlled by SON of digital input(DI). ١: Software force to servo on.	٠.١	٠
٥٤	The delay closing time of servo enable	It defines the time to delay cutting off the motor current after the servo enable signal is turned off.	٠.٣٠٠٠٠ms	٠

No.	Name	Function	Rang	Default Value								
00	Effective level control word of input terminals	<p>1.To reverse the input terminals. For unreversed terminals, it is valid when the switch is closed, while it is invalid when the switch is open. For reversed terminals, it is invalid when the switch is closed, while it is valid when the switch is open.</p> <p>2.Represented by a binary digit of 4 bits. If it is 0, it means the input terminal dose not reverse. While it is 1, it means the terminal reverses.</p> <p>The binary digit represents the input terminals as following:</p> <table><tr><td>3</td><td>2</td><td>1</td><td>0</td></tr><tr><td>DI3</td><td>DI2</td><td>DI1</td><td>DI0</td></tr></table> <p>0: high level is active.</p> <p>1: low level is active.</p>	3	2	1	0	DI3	DI2	DI1	DI0	0000-1111	0000
3	2	1	0									
DI3	DI2	DI1	DI0									
01	Effective level control word of output terminals	<p>1.To reverse the output terminals. For reversed terminals,the definitions of breaking over and cut-off is contrary to standard definitions</p> <p>2.Represented by a binary digit of 4 bits. If it is 0, it means the input terminal dose not reverse. While it is 1, it means the terminal reverses.</p> <p>The binary digit represents the input terminals as following:</p> <table><tr><td>3</td><td>2</td><td>1</td><td>0</td></tr><tr><td>DO3</td><td>DO2</td><td>DO1</td><td>DO0</td></tr></table> <p>0: high level is active.</p> <p>1: low level is active.</p>	3	2	1	0	DO3	DO2	DO1	DO0	0000-1111	0000
3	2	1	0									
DO3	DO2	DO1	DO0									
0A	Removing jitter time constant of I/O input	<p>1.Set the removing jitter filter time for input terminal.</p> <p>2.The value is smaller, the terminal input response frequency is quicker.</p> <p>3.The value is bigger, the anti-jamming</p>	1-20ms	2								

	terminal	performance of input terminal is better, but the response frequency becomes slow.		
09	Effective command pulse edge	Set to: 0: the rising edge is effective. 1: the falling edge is effective.	0-1	0
10	Soft reset	Set to: 0: Soft reset is invalid. 1: Soft reset is effective and the system will restart.	0-1	0
11	System alarm clear	Set to: 0: System alarm clear is invalid. 1: System alarm clear is effective.	0-1	0
12	Encoder selection	Set to: 0: IO incremental 1000-line encoder. 1: IO save-wiring 1000-line encoder.	0-1	Decided by motor
13	Load inertia ratio	Set the load inertia ratio of the motor rotating inertia. The setting value = ((load inertia + rotating inertia) / rotating inertia) × 100.	1-1000	100
14	Internal Torque 0	In torque control mode (PA0=1), when TRQ0=OFF, TRQ1=OFF, internal torque 0 is as the torque command.	-300-300	0
15	Internal Torque 1	In torque control mode (PA0=1), when TRQ0=ON, TRQ1=OFF, internal torque 1 is as the torque command.	-300-300	0
16	Internal Torque 2	In torque control mode (PA0=1), when TRQ0=OFF, TRQ1=ON, internal torque 2 is as the torque command.	-300-300	0
17	Internal Torque 3	In torque control mode (PA0=1), when TRQ0=ON, TRQ1=ON, internal torque 3 is as the torque command.	-300-300	0
18	MODBUS ID NO.	MODBUS communication address.	1-255	1

No.	Name	Function	Rang	Default Value
٧٢	MODBUS communication baud rate	MODBUS communication baud rate.	٤٨-١١٥٢× ١٠٠	٩٦
٧٣	MODBUS protocol selection	<p>٠: ٨, N, ٢ (MODBUS, RTU)</p> <p>١: ٨, E, ١ (MODBUS, RTU)</p> <p>٢: ٨, O, ١ (MODBUS, RTU)</p> <p>The parameter decide the communication protocol. Value ٨ represents the transmitted data is ٨ bits; N,E,O indicate odd or even:</p> <p>N: do not use this bit.</p> <p>E: it represents ١ is even bit.</p> <p>O: it represents ١ is odd bit.</p> <p>Value ١ or ٢ indicates communication of ١ bit or ٢ bits.</p>	٠-٣	٠
٧٤	Communication error handling	<p>When communication happens error, if choose:</p> <p>٠: keep working.</p> <p>١: alarm and stop working.</p>	٠-١	٠
٧٥	Zero-speed detection point	<p>١. If the motor running speed is less than the value of this parameter, the ZSP(zero speed) of digital output(DO) is ON, or else OFF.</p> <p>٢. If ZCLAMP of digital input(DI) is ON and speed command is less than the value of this parameter, the value of speed command is forced to be zero.</p>	٠-١٠٠٠ r/min	١٠
٧٦	Speed coincidence range	When the difference between the actual speed and the instruction speed is less than this setting, the UCOYN(speed coincidence) is ON, otherwise OFF.	٠-١٠٠٠ r/min	١٠

ⅤⅤ	Ⅲ rd numerator of electronic gear for position command pulse	Refers to parameter PA1Ⅲ.	0.32767	.
ⅤⅧ	Ⅳ th numerator of electronic gear for position command pulse	Refers to parameter PA1Ⅳ.	0.32767	.
ⅤⅨ	Ⅴ th numerator of electronic gear for position command pulse	Refers to parameter PA1Ⅴ.	0.32767	.
Ⅷ0	Effective level of command direction signal	Set to: 0:High level is positive direction. 1:Low level is positive direction.	0.1	.
Ⅷ1	PULS signal filter of command pulse	1.To filter the input PULS signal. 2.The default value is the max pulse input frequency: 0.0KHz(kpps). The value is bigger, the max input frequency is slower. 3.To filter the noise from the signal line in order to avoid incorrect counting happening. If it goes wrong due to the incorrect counting, you can increase the value of this parameter properly. 4. After editing this parameter, please save it and recharge. Then it is effective.	0.10	4
Ⅷ2	SIGN signal filter of command pulse	1.To filtering the input SIGN signal. 2.The default value is the max pulse input frequency: 0.0KHz(kpps) The value is bigger, the max input frequency is slower. 3.To filter the noise from the signal line in order to avoid incorrect counting happening. If it goes wrong due to the incorrect counting,	0.10	4

		<p>you can increase the value of this parameter properly.</p> <p>ξ. After edited this parameter, must save it and recharge. Then it is effective.</p>		
83	CWL/CCWL inhibit way	<p>When the machine touches the mechanical limit switch and strike CW/CCW limit , you can choose the following methods to prohibit with this parameters.</p> <p>•: To limit the torque in this direction to be •.</p> <p>∖: To prohibit the input pulse in this direction.</p>	•-∖	•
84	Hysteresis for positioning completion	<p>∖. Set pulse completion range in position control mode.</p> <p>γ. when the number of remaining pulses in the position deviation counter is less than or equal to the setting value of this parameter, the digital output of COIN(position completion) is ON, otherwise OFF.</p> <p>γ. Comparator has the function of hysteresis, which is set by PA⁸⁵.</p>	•-32767 pulses	70
85	The range of near position	<p>∖. To set the pulse range of near position under the position control mode.</p> <p>γ. When the pulse number in position deviation counter is smaller than or equal to the setting value of this parameter, the digital output (DO) NEAR(approach position) is ON, otherwise is OFF.</p> <p>γ. The comparator has hysteresis function set by PA⁸⁶.</p> <p>ξ. Use this function in case that in near positioning, the host controller is accepting the NEAR signal to carry on the preparation to the next step. In general, this parameter value should be bigger than PA⁸⁶.</p>	•-32767 pulses	70..

△△	Hysteresis for approach positioning	Refer to parameter PA△△.	0.32767 pulses	60.											
△△	Hysteresis of arrival speed	<p>1. When the motor speed exceeds this parameter, the digital output ASP (speed arrival) is ON, otherwise OFF.</p> <p>2. The comparator has hysteresis function.</p> <p>3. It has polarity setting function:</p> <table><tr><td>PA△△</td><td>PA△△</td><td>Comparator</td></tr><tr><td>0</td><td>>0</td><td>Speed without direction</td></tr><tr><td rowspan="2">1</td><td>>0</td><td>Only detect positive speed</td></tr><tr><td><0</td><td>Only detect reversal speed</td></tr></table>	PA△△	PA△△	Comparator	0	>0	Speed without direction	1	>0	Only detect positive speed	<0	Only detect reversal speed	0.0000 r/min	3.
PA△△	PA△△	Comparator													
0	>0	Speed without direction													
1	>0	Only detect positive speed													
	<0	Only detect reversal speed													
△△	Polarity of arrival speed	Refers to parameter PA△△.	0.1	0											
△△	Arrival torque	<p>1. When the motor torque exceeds this parameter, the digital output ATRQ (torque arrival) is ON, otherwise OFF.</p> <p>2. The comparator has hysteresis function set by PA△△.</p> <p>3. It has polarity setting function:</p> <table><tr><td>PA△△</td><td>PA△△</td><td>Comparator</td></tr><tr><td>0</td><td>>0</td><td>Torque without direction</td></tr><tr><td rowspan="2">1</td><td>>0</td><td>Only detect positive speed</td></tr><tr><td><0</td><td>Only detect reversal speed</td></tr></table>	PA△△	PA△△	Comparator	0	>0	Torque without direction	1	>0	Only detect positive speed	<0	Only detect reversal speed	-3.00%~3.00%	1.0
PA△△	PA△△	Comparator													
0	>0	Torque without direction													
1	>0	Only detect positive speed													
	<0	Only detect reversal speed													
△△	Hysteresis of arrival torque	<p>1. If the motor torque is bigger than PA△△, the ATRQ(torque arrival) of digital output(DO) is ON, otherwise it is OFF.</p> <p>2. The comparator has hysteresis function set by PA△△.</p> <p>3. It also has polarity setting function:</p> <table><tr><td>PA△△</td><td>PA△△</td><td>Comparator</td></tr><tr><td>0</td><td>>0</td><td>Torque without direction</td></tr><tr><td rowspan="2">1</td><td>>0</td><td>Only detect positive speed</td></tr><tr><td><0</td><td>Only detect reversal speed</td></tr></table>	PA△△	PA△△	Comparator	0	>0	Torque without direction	1	>0	Only detect positive speed	<0	Only detect reversal speed	0.3000%	0
PA△△	PA△△	Comparator													
0	>0	Torque without direction													
1	>0	Only detect positive speed													
	<0	Only detect reversal speed													

91	Polarity of arrival torque	1. If the motor torque is bigger than PA91, the ATRQ(torque arrival) of digital output(DO) is ON, otherwise it is OFF. 2. The comparator has hysteresis function and it is set by PA90. 3. It also has polarity setting function:	0-1	0
		PA91	PA90	Comparator
		0	>0	Torque without direction
		1	>0	Only detect positive speed
			<0	Only detect reversal speed
92	Hysteresis of zero speed detection	1. The motor speed is lower than the value of this parameter, ZSP(zero speed) of digital output is ON, or else OFF. 2. The comparator has hysteresis function.	0-1000 r/min	0
93	The delay time of brake on	This parameter defines the delay time from the servomotor energized until the action(the digital output(DO) BRK is ON .	0-200 ms	0
94	Motor encoder resolution	Motor encoder resolution, 256=13107 and the setting value 17. Please modify it carefully.	10-32	17
95	Motor polarity	It is motor polarity. Please modify it carefully.	1-360	0
96	Maximum duty cycle on brake	Maximum duty cycle on brake	0-90	00
97	Filter selection of position loop	0 : digital moving average filter. 1 : index smooth filter.	0-1	0

Ⅴ.ⅡP Group Parameters For Multifunctional Terminals

Ⅴ.Ⅱ.Ⅰ Parameter Table

P series servo drives have 4 input terminals and 4 output terminals. The definition values can be set by P group parameters.(Low level is effective as default for input terminals).

Parameter	Name	Range	Default Value
P3-1	Digital Input DI1 Function	0-99	1
P3-2	Digital Input DI2 Function	0-99	2
P3-3	Digital Input DI3 Function	0-99	3
P3-4	Digital Input DI4 Function	0-99	4
P3-5	Digital Input DI5 Function	0-99	5
P3-6	Digital Input DI6 Function	0-99	6
P3-7	Digital Input DI7 Function	0-99	7
P3-8	Digital Input DI8 Function	0-99	8
P3-13	Low 8-bit current position value	-32768 - 32767	0
P3-14	High 8-bit current position value	-32768 - 32767	0
P3-15	Digital Input DI forced effective1	0000000-1111111	0000000
P3-16	Digital Input DI forced effective2	0000000-1111111	0000000
P3-17	Digital Input DI forced effective3	0000000-1111111	0000000
P3-18	Digital Input DI forced effective4	0000000-1111111	0000000
P3-19	Digital Input DI forced effective5	0000000-1111111	0000000
P3-20	Digital Output DO1 Function	0-99	18
P3-21	Digital Output DO2 Function	0-99	3
P3-22	Digital Output DO3 Function	0-99	5
P3-23	Digital Output DO4 Function	0-99	8
P3-24	Digital Output DO5 Function	0-99	6
P3-25	Digital Output DO6 Function	0-99	7

P3-30	Virtual Input Terminal Control	0-2	0
P3-31	The State Value Of Virtual Input Terminal	0000000-11111111	0000000
P3-32	Virtual Output Terminal Control	0-1	0
P3-33	The State Value Of Virtual Output Terminal	0000-1111	0000
P3-38	Virtual I/O Input DI1 Function	0-99	0
P3-39	Virtual I/O Input DI2 Function	0-99	0
P3-40	Virtual I/O Input DI3 Function	0-99	0
P3-41	Virtual I/O Input DI4 Function	0-99	0
P3-42	Virtual I/O Input DI5 Function	0-99	0
P3-43	Virtual I/O Input DI6 Function	0-99	0
P3-44	Virtual I/O Input DI7 Function	0-99	0
P3-45	Virtual I/O Input DI8 Function	0-99	0
<p>Remark:</p> <p>1. P3-30=0, the number of IO input is 4 decided by DI1~DI4 and the corresponding parameter P3-38~P3-43;</p> <p>2. P3-30=1, the number of IO input is 8 decided by P3-31 and the corresponding parameter P3-38~P3-45;</p> <p>P3-30=2, the number of IO input is 16 decided by DI1~DI8 and P3-31 and the corresponding parameter P3-38~P3-43 and P3-38~P3-45.</p>			

Ⅴ,Ⅵ,Ⅶ **DI Function Explanation**

Input terminals(^ input terminals are corresponding to the definitions of PⅤ-Ⅰ,PⅤ-Ⅱ,PⅤ-Ⅲ,PⅤ-Ⅳ).

Value	Symbol	Function	Explanation
Ⅰ	NULL	No	Input state dose not effect system.
Ⅱ	SON	Servo Enable	Input terminal of servo enable. OFF: servo driver can not be enabled and serv omotor is not excited. ON:servo driver is enabled and servomotor is excited.
Ⅲ	ARST	Alarm Clear	Input terminal of alarm clearance. When an alarm occurs and if the alarm is allowed clearance, the rising edge(from OFF becomes ON) of ARST will clear the alarm. Attention: only a part of alarms are allowed to clear.
Ⅳ	CCWL	CCW Drive Inhibition	Ⅰ. Input terminal of CCW drive inhibition: OFF: Inhibit CCW running. ON: Enable CCW running. Ⅱ. Use this function for protection of the mechanical traveling limit.The function is controlled by the parameter PAⅣⅠ. Pay attention to that the default value of PAⅣⅠ neglects this function.Therefore needs to modify PAⅣⅠ if need to use this function: (Ⅰ): When PAⅣⅠ=Ⅰ, the function of input inhibition is effective. Whether to inhibit is decided by PAⅣⅡ. (Ⅱ): When PAⅣⅠ=Ⅱ, the function of input inhibition is not effective. Whether to inhibit is not decided by PAⅣⅡ Ⅲ. Inhibition function is valid(PAⅣⅠ=Ⅰ): (Ⅰ) PAⅣⅡ=Ⅰ, CCW torque limit is Ⅰ,but it does not limit CCW pulse input. (Ⅱ) PAⅣⅡ=Ⅱ, it does not inhibit CCW pulse input.
Ⅴ	CWL	CW Drive Inhibition	Ⅰ.The input terminal of CW drive inhibition OFF : Inhibit CCW running. ON: Enable CW running.

			<p>1. Use this function for protection of the mechanical traveling limit. The function is controlled by the parameter PA10. Pay attention to that the default value of PA10 neglects this function. Therefore needs to modify PA10 if need to use this function:</p> <p>(1): When PA10=0, the function of input inhibition is effective. Whether to inhibit for CW is decided by PA13.</p> <p>(2): When PA10=1, the function of input inhibition is not effective. Whether to inhibit for CW is not decided by PA13</p> <p>2. Inhibition function is valid(PA10=0):</p> <p>(1): PA13=0, CW torque limit is 0, but it does not limit CW pulse input.</p> <p>PA13=1, it does not inhibit CW pulse input.</p>
0	TCCW	CCW Torque Limitation	<p>OFF: Torque is not limited by parameter PA16 in CCW direction.</p> <p>ON: Torque is limited by parameter PA16 in CCW direction.</p> <p>Attention: Whether the TCCW is effective or not, the torque is also limited by PA15 in CCW direction.</p>
1	TCW	CW Torque Limitation	<p>OFF: Torque is not limited by parameter PA17 in CW direction.</p> <p>ON: Torque is limited by parameter PA17 in CW direction.</p> <p>Attention: Whether the TCW is effective or not, the torque is also limited by PA15 in CW direction.</p>
2	ZCLAMP	Zero Speed Clamping	<p>When it is satisfied with the followings, the function of zero speed clamping is open(speed is forced to zero):</p> <p>1: speed control mode(PA14=1), and choose external speed(PA12=0);</p> <p>2: ZCLAMP ON;</p>

			<p>٣ : speed command is lower than the value of PA٧٥</p> <p>When any one of the above conditions is not satisfied, it will perform normal speed control.</p>
٨	CZERO	Zero Command	<p>In speed or torque control mode, speed or torque command:</p> <p>OFF: Normal command</p> <p>ON:: Zero command</p>
٩	CINV	Instruction Reverse	<p>In speed or torque control mode, speed or torque command:</p> <p>OFF: Normal command</p> <p>ON: Command reversed</p>
١٠	SP١	Speed Choice ١	<p>In speed control mode(PA٤=١), and choose internal speed(PA٧٧=١). SP١ and SP٣ combinations are used to select different internal speeds:</p> <p>SP٣ OFF SP١ OFF: internal speed ١(PA-٧٤)</p> <p>SP٣ OFF SP١ ON: internal speed ٣(PA-٧٥)</p> <p>SP٣ ON SP١ OFF: internal speed ٣(PA-٧٦)</p> <p>SP٣ ON SP١ ON: internal speed ٤(PA-٧٧)</p>
١١	SP٣	Speed Choice ٣	
١٣	TRQ١	Torque Choice ١	<p>In torque control mode(PA٤=٣), and choose internal torque(PA٧٧=١). TRQ١ and TRQ٣ combinations are used to select different internal torque:</p> <p>TRQ٣ OFF TRQ١ OFF: internal torque ١(PA٦٤)</p> <p>TRQ٣ OFF TRQ١ ON: internal torque ٣(PA٦٥)</p> <p>TRQ٣ ON TRQ١ OFF: internal torque ٣(PA٦٦)</p> <p>TRQ٣ ON TRQ١ ON: internal torque ٤(PA٦٧)</p>
١٤	TRQ٣	Torque Choice ٣	
١٦	CMODE	Composite Mode	<p>When PA٤ is set to ٣, ٤, ٥, it is in mix control mode. It can change control mode with this input terminal:</p> <p>(١) PA٤=٣, CMODE OFF, it is position control mode; CMODE ON, it is speed control mode;</p> <p>(٣) PA٤=٤, CMODE OFF, it is position control mode; CMODE ON, it is torque control mode;</p> <p>(5) PA٤=٥, CMODE OFF, it is speed control mode; CMODE ON, it is torque control mode.</p>

18	GEAR1	Electronic Gear 1	When PA11=0, Gear1 and Gear2 combinations are used to select different numerator of gear ratio: GEAR2 OFF GEAR1 OFF: numerator 1 (PA-12) GEAR2 OFF GEAR1 ON: numerator 2 (PA-13) GEAR2 ON GEAR1 OFF: numerator 3 (PA-14) GEAR2 ON GEAR1 ON: numerator 4 (PA-15)
19	GEAR2	Electronic Gear 2	
20	CLR	Position Deviation Clear	In position control mode, the position deviation counter clear input terminals.
21	INH	Pulse Input Inhibition	In position control mode, position command pulse inhibit terminals: OFF: The input command pulse is valid. ON : The input command pulse input is prohibited.
22	JOGP	CCW Inching	In speed control mode, PA22=0, connect to the signal, the motor is in inching in CCW and speed is set by PA21. Attention: If the signal is connected to CW inching, inching function does not work.
23	JOGN	CW Inching	In speed control mode, PA23=0, connect to the signal, the motor is in inching in CW and speed is set by PA21. Attention: If the signal is connected to CCW inching, inching function does not work.
24	HOLD	Internal Position Control Command Stops	In internal position register mode, the motor will stop rotating if the signal is active(It can only work when internal position mode PA-14=3).
25	CTRG	Internal Position Command Triggers	In internal position register mode, the signal will be triggered once the internal position register control commands(POS0-3) are chosen, and then the motor will rotate according to the internal position register command. Only when ZSPD=1(digital output) it would receive a next internal position command trigger.

Ⅲ. 9	POS. 1	Internal Position Command Selection 1	The corresponding relationship of the internal position selection:					
			Position Command	POS. 1	POS. 2	POS. 3	CTRG	Parameter
			P. 1	.	.	.	↑	P. 1. 2 P. 1. 3
			P. 2	.	.	.	↑	P. 1. 4 P. 1. 5
Ⅲ. 10	POS. 2	Internal Position Command Selection 2	P. 3	.	.	.	↑	P. 1. 6 P. 1. 7
			P. 4	.	.	.	↑	P. 1. 8 P. 1. 9
			P. 5	.	.	.	↑	P. 1. 10 P. 1. 11
			P. 6	.	.	.	↑	P. 1. 12 P. 1. 13
Ⅲ. 11	POS. 3	Internal Position Command Selection 3	P. 7	.	.	.	↑	P. 1. 14 P. 1. 15
			P. 8	.	.	.	↑	P. 1. 16 P. 1. 17
			P. 9	.	.	.	↑	P. 1. 18 P. 1. 19
			P. 10	.	.	.	↑	P. 1. 20 P. 1. 21
			P. 11	.	.	.	↑	P. 1. 22 P. 1. 23
			P. 12	.	.	.	↑	P. 1. 24 P. 1. 25
Ⅲ. 12	SHOM	Starting Origin Regression	In internal position register mode, it needs to search for origin. The signal turns on and starts searching for the origin function(Refer to the setting of P. 1. 26).					
Ⅲ. 13	ORGP	Origin Of Regression	In internal position register mode, it needs to search for origin. The signal turns on and starts searching for the origin function(Refer to the setting of P. 1. 27).					

V, 2, 3 DO Function Explanation

Output terminals(1 input terminals are corresponding to the definitions of P2-20, P2-21, P2-22, P2-23).

Value	Symbol	Function	Explanation
1	ON	Always Valid	Forced output ON.
2	RDY	Servo Ready	OFF : Main power supply is off, or alarm occurs; ON: Main power supply is normal, no alarm occurs
3	ALM	Alarm	OFF : alarm occurs. ON : no alarm occurs.
4	ZSP	Zero Speed	In speed or torque control mode: OFF: motor speed is higher than the value of PA20 (no direction). ON: motor speed is higher than the value of PA20 (no direction).
5	COIN	Positioning Completion	In position control mode: OFF: position deviation is bigger than parameter PA16. ON: position deviation is bigger than parameter PA16.
6	ASP	Arrival Speed	In speed or torque control mode: OFF : motor speed is lower than parameter PA28. ON : motor speed is higher than parameter PA28. Polarity function can be set referring to the explanation of PA28.
7	ATRQ	Arrival Torque	OFF : motor torque is lower than parameter PA89; ON : motor torque is higher than parameter PA89. Polarity function can be set referring to the explanation of PA89.
8	BRK	Electromagnetic Brake	OFF : electromagnetic brake applies the brake. ON : electromagnetic brake releases the brake.
9	RUN	Servo Running	OFF : servo motor does not excite. ON : servo motor has excited.
10	NEAR	Near Position	In position control mode: OFF: position deviation is bigger than parameter PA80. ON: position deviation is smaller than parameter PA80.

11	TRQL	Torque Limitation	<p>OFF : motor torque has not reached the limitation.</p> <p>ON : motor torque has reached the limitation.</p> <p>Torque limitation is set by PA³⁴, PA³⁵, PA³⁶ and PA³⁷.</p>
12	SPL	Speed Limitation	<p>In torque control mode:</p> <p>OFF : motor speed has not reached the limitation.</p> <p>ON : motor speed has reached the limitation.</p> <p>Speed limitation is set by PA³⁸.</p>
13	VCOIN	Speed Consistency	<p>OFF: The absolute value of the difference between the actual rotational speed and the instruction speed is bigger than PA³⁹.</p> <p>ON: The absolute value of the difference between the actual rotational speed and the instruction speed is smaller than PA³⁹.</p>
15	HOME	Origin Regression Completion	<p>OFF: No signal output when the origin regression doesn't complete.</p> <p>ON: The signal outputs when the origin regression completes.</p>
16	CMDOK	Internal Position Command Completion	<p>OFF: No signal output when internal position command doesn't complete or internal position command doesn't stop.</p> <p>ON: The signal outputs after the setting time of P⁴⁻¹ when internal position command completes or internal position command stops.</p>

V, V, 4

DI Forced Valid

There are 8 parameters (P^r-10, P^r-16, P^r-17, P^r-18, P^r-19) in group P^r and they can force DI valid.

(1) Corresponding functions for P^r-10 is represented by 8-bit binary:

Number	Bit ^V	Bit ¹	Bit ⁰	Bit ⁴	Bit ³	Bit ²	Bit ¹	Bit ⁰
Function	CZERO	ZCLAMP	TCW	TCCW	CWL	CCWL	ARST	SON

(2) Corresponding functions for P^r-16 is represented by 8-bit binary:

Number	Bit ^V	Bit ¹	Bit ⁰	Bit ⁴	Bit ³	Bit ²	Bit ¹	Bit ⁰
Function	CMODE	NULL	TRQ ^V	TRQ ¹	NULL	SP ^V	SP ¹	CINV

(3) Corresponding functions for P^r-17 is represented by 8-bit binary:

Number	Bit ^V	Bit ¹	Bit ⁰	Bit ⁴	Bit ³	Bit ²	Bit ¹	Bit ⁰
Function	NULL	JOGN	JOGP	INH	CLR	GEAR ^V	GEAR ¹	NULL

(4) Corresponding functions for P^r-18 is represented by 8-bit binary:

Number	Bit ^V	Bit ¹	Bit ⁰	Bit ⁴	Bit ³	Bit ²	Bit ¹	Bit ⁰
Function	NULL	POS ^V	POS ¹	POS ⁰	CTRG	HOLD	NULL	NULL

(5) Corresponding functions for P^r-19 is represented by 8-bit binary:

Number	Bit ^V	Bit ¹	Bit ⁰	Bit ⁴	Bit ³	Bit ²	Bit ¹	Bit ⁰
Function	NULL	NULL	NULL	NULL	NULL	NULL	ORGP	SHOM

Parameter Meaning:

One of 0 parameters	Corresponding Function	Result
0	Unplanned	OFF (invalid)
	Already Planned	It is up to signals
1	Unplanned Or Already Planned	ON (forced valid)



◆ Being planned means that the parameter has been selected by the input terminal in the P^r-0~P^r-3.

Ⅴ.Ⅲ PⅤ Group Parameters For Internal Position Command


No.	Name	Function	Rang	Default Value
PⅤ-Ⅰ	Internal position instruction control mode	Ⅰ: absolute position instruction. Ⅱ: incremental position instruction.	Ⅰ-Ⅱ	Ⅰ
PⅤ-Ⅱ	The digital output delay of internal position completion	Ⅰ. When the internal position command is completed or stops, the output internal position command completes (CMDOK) this DO signal after the delay time set by PⅤ-Ⅱ. Ⅱ. Only when the delay time PⅤ-Ⅱ=Ⅰ and CMDOK=Ⅱ can it receive trigger internal position command. Ⅲ. Only when the delay time PⅤ-Ⅱ is not Ⅰ and CMDOK=Ⅱ can it receive the internal position command triggered by CTRG.	Ⅰ-ⅡⅠⅠms	Ⅰ
PⅤ-Ⅲ	The setting of position cycle numbers for internal position command Ⅱ	To set position cycles of the first internal position.	-ⅢⅠⅠⅠⅠ-ⅢⅠⅠⅠ	Ⅰ
PⅤ-Ⅳ	The setting of pulse number in position cycle for internal position command Ⅱ	Ⅰ. To set position pulses of the first internal position. Ⅱ. Internal position command=the setting value of the first internal position cycles+the setting value of the first internal position pulses. (Max is the pulse number of the motor rotation for each roll, please refer to the settings of PAⅠⅠ, PAⅠⅡ and PAⅠⅢ).	+/-max. cnt/rev	Ⅰ

P ₅₋₅	The move speed of internal position instruction ⑤	To set the move speed of internal position instruction ⑤.	0.0000 r/min	0.000
P ₅₋₆	The number of position cycles of internal position instruction ⑥	To set the number of position cycles of the second stage internal position.	-30000- 30000	0
P ₅₋₇	The pulse number setting in position loop of internal position instruction ⑦	⑤. To set the position pulses of the second stage internal position. ⑦. Internal position instruction ⑦=the position cycles setting of the second internal position+the pulse number setting of the second internal position.	+/-max. cnt/rev	0
P ₅₋₈	The move speed of internal position instruction ⑧	To set the move speed of internal position instruction ⑧.	0.0000 r/min	0.000
P ₅₋₉	The position cycles of internal position instruction ⑨	To set the position cycles of the third stage internal position instruction.	-30000- 30000	0
P ₅₋₁₀	The pulse number setting in position loop of internal position instruction ⑩	⑤. To set the position pulses of the third stage internal position. ⑩. Internal position instruction ⑩=the position cycles setting of the third internal position+the pulse number setting of the third internal position.	+/-max. cnt/rev	0

Pε-10	The move speed of internal position instruction ϑ	To set the move speed of internal position instruction ϑ.	0.0000 r/min	1000
Pε-11	The number of position cycles of internal position instruction ε	To set the number of position cycles of the fourth stage internal position.	-30000- 30000	0
Pε-12	The pulse number setting in position loop of internal position instruction ε	1. To set the position pulses of the ε th stage internal position. 2. Internal position instruction ε=the position cycles setting of the ε th internal position+the pulse number setting of the ε th internal position.	+/-max. cnt/rev	0
Pε-13	The move speed of internal position instruction ε	To set the move speed of internal position instruction ε.	0.0000 r/min	1000
Pε-14	The position cycles of internal position instruction ρ	To set the position cycles of the ρ th stage internal position instruction.	-30000- 30000	0
Pε-15	The pulse number setting in position loop of internal position instruction ρ	1. To set the position pulses of the ρ th stage internal position. 2. Internal position instruction ϑ=the position cycles setting of the ρ th internal position+the pulse number setting of the third internal position.	+/-max. cnt/rev	0

Pε-16	The move speed of internal position instruction ρ	To set the move speed of internal position instruction ρ.	0.0000 r/min	1000
Pε-17	The number of position cycles of internal position instruction 1	To set the number of position cycles of the sixth stage internal position.	-30000 30000	0
Pε-18	The pulse number setting in position loop of internal position instruction 1	1. To set the position pulses of the 1 th stage internal position. 2. Internal position instruction 1=the position cycles setting of the 1 th internal position+the pulse number setting of the 1 th internal position.	+/-max. cnt/rev	0
Pε-19	The position cycles of internal position instruction 2	To set the position cycles of the 2 th stage internal position instruction.	0.0000 r/min	1000
Pε-20	The position cycles of internal position instruction 2	To set the position cycles of the 2 th stage internal position instruction.	-30000 30000	0
Pε-21	The pulse number setting in position loop of internal position instruction 2	1. To set the position pulses of the 2 th stage internal position. 2. Internal position instruction 2=the position cycles setting of the 2 th internal position+the pulse number setting of the 2 th internal position.	+/-max. cnt/rev	0

Pε-22	The move speed of internal position instruction ∇	To set the move speed of internal position instruction ∇.	0.0000 r/min	1.000
Pε-23	The number of position cycles of internal position instruction ^	To set the number of position cycles of the eighth stage internal position.	-3.0000 3.0000	1
Pε-24	The pulse number setting in position loop of internal position instruction ^	1. To set the position pulses of the ^th stage internal position. 2. Internal position instruction ^=the position cycles setting of the ^th internal position+the pulse number setting of the ^th internal position.	+/-max. cnt/rev	1
Pε-20	The move speed of internal position instruction ^	To set the move speed of internal position instruction ^.	0.0000 r/min	1.000
Pε-25	The type of origin detector and setting of finding direction	0: Forward direction origin regression and CCWL is as regression origin. 1: Reverse direction origin regression and CWL is as regression origin. 2: Forward direction origin regression and ORGP is as regression origin. 3: Reverse direction origin regression and ORGP is as regression origin. 4: Forward looking for Z pulse as the origin of regression. 5: Reverse looking for Z pulse as the origin of regression.	0.00	1

Pε-33	Set the mode of short distance movement to the origin	<p>•: Find the reference origin and return to search for the Z phase pulse as the mechanical origin.</p> <p>∧: Find the reference origin and keep forward for the Z phase pulse as the mechanical origin.</p> <p>∇: Find the rising edge of the detector ORGP as the mechanical origin.</p> <p>(when it is ∇, only the type of origin detector and the setting value of the search direction can be used as ∇, ∇, ε or ∘.)</p>	•-2	•
Pε-34	Origin trigger start mode	<p>•: Close origin regression function.</p> <p>∧: Automatically perform origin regression when it is powering on.</p> <p>∇: Trigger the origin regression function by the input contact of the origin search function.</p>	•-2	•
Pε-35	The setting of origin stop mode	<p>•: The motor slows down and pulls back to the origin when the origin detection completed.</p> <p>∧: The motor slows forward and stops when the origin detection completed.</p>	•-1	•
Pε-36	The speed setting of origin regress in the first stage of high speed (HSPD∧)	<p>To set homing speed at ∧st stage.</p> 	1-2... r/min	1...
Pε-37	The speed setting of origin regress in the first stage of high speed(HSPD∇)	<p>To set the speed of origin regression in the second stage of high speed.</p>	1-5... r/min	5.

P٤.٣٨	The cycle number of origin regression offset(HOF١)	To set the cycle number of origin regression offset.	-٣. . . . - ٣.
P٤.٣٩	The pulse number of origin regression offset(HOF٢)	١: To set the pulse number of origin regression offset. ٢: When the parameter function HOF١ and HOF٢ are set to ., the origin is defined as Z pulse or ORGP by the origin regression mode. If they are not ., the origin will define the above Z pulse plus last pulse offset HOF١ \times ١. . . . +HOF٢ as the new origin.	+/-max. cnt/rev	.



Chapter ^ Error Code

No.	Error Name	Introduction
--	Normal	
၁	Over speed	Motor speed over than the setting values.
၂	Main circuit over voltage	The voltage of main circuit is too high
၃	Main circuit under voltage	The voltage of main circuit is too low
၄	Position overshoot	The value of position deviation counter is over than the setting value.
၅	Drive overheat	The temperature of the drive is high
၆	Speed amplifier saturation fault	Speed adjustment for long time saturation
၇	Drive inhibit error	Speed adjustment in saturation for long time
၈	Position deviation accumulation was out of range	Absolute value of position deviation accumulation is over than ၃၃°.
၁၁	IPM module error	IPM smart module error
၁၃	Drive overload	Servo drive and motor overload(overheat instantaneously)
၁၄	Brake fault	Brake circuit Error
၁၈	Relay switch fault	The real state of relay is different from control state
၁၉	Delay to open the brake	Pulse inputs before opening
၂၀	EEPROM error	EEPROM error
၂၁	FPGA module fault	FPGA module fault
၂၃	Current collecting circuit fault	Current collecting circuit fault
၂၉	Alarm for torque overload	Motor load exceeds user-set values and range
၃၈	Failure to read or write encoder EEPROM communication	The encoder cable was not connected Or the encoder interface circuit fault.
၃၉	Data CRC checking error	The motor encoder hasn't written dataes and all are ၀.
၄၀	Model not supported	Driver does not support this motor model
၄၁	Need to switch motor model	The current motor is inconsistent with the selected model of the drive.
၄၂	AC input under voltage	AC input under voltage
၄၇	Over voltage when main circuit in powering up	Over voltage when main circuit in powering up

00	Encoder communication fault	Driver and encoder are not connected
01	Encoder communication abnormal	After the encoder established the communication, there appears the interrupt and disconnection.
02	Encoder battery voltage insufficient alarm	Encoder battery voltage insufficient alarm, but information did not lost and needs to be replaced as soon as possible.
03	Encoder battery voltage error alarm	Encoder battery voltage error alarm, and storage information has occurred error needing to reset encoder.
04	Encoder error alarm	Encoder non-battery alarm, but need to reset encoder again.
05	CRC check occurs errors for 3 times in a row	Encoder communication received data CRC validation 3 consecutive errors.
06	MODBUS frame is too long.	MODBUS frame data received is too long
07	Abnormal MODBUS communication format	Improper setting of communication parameters or incorrect address or value
08	Single turn position error	Single turn position offset stored by the drive exceeds encoder resolution
09	Encoder reporting CF error	Encoder continuously reports CF domain error and is needed reset encoder

۰۲۱۳۳۳۹۱۴۱۸-۰۲۱۳۳۳۹۱۴۱۹
۰۹۱۹۷۷۴۵۱۵۹-۰۹۲۰۷۷۴۵۱۵۹

www.prolinecnc.ir



