



PROLINECNC

NG100A Series Servo Drive Quick Start Guide(EN, FR, DE)

Directory

1	Specification and Installation	۱
۱,۱	Model Number.....	۲
۱,۲	Electrical Specifications.....	۲
۱,۳	General Specifications	۳
۱,۴	Installation Dimensions.....	۴
2	Wiring	۵
۲,۱	Servo System Wiring Diagram	۷
۲,۲	Wiring of the Main Circuit.....	۹
۲,۲,۱	Main Circuit Terminals	۹
۲,۲,۲	Circlip type terminal connection method	۱۰
۲,۲,۳	Specifications of Main Circuit Cables.....	۱۰
۲,۳	Wiring of the regenerative resistor.....	۱۱
۲,۳,۱	Wiring of external regenerative resistor	۱۱
۲,۳,۲	Regenerative resistor specifications	۱۱
۲,۴	Wiring of the brake	۱۲
۲,۵	Port definition and wiring of control terminal (CN ^۱)	۱۳
۲,۵,۱	Port definition of control terminal (CN ^۱).....	۱۳
۲,۵,۲	Wiring of Digital input.....	۱۵
۲,۵,۳	Wiring of Digital output.....	۱۸
۲,۵,۴	Wiring of encoder frequency division output signals.....	۲۱
۲,۵,۵	Wiring of position reference input signals	۲۲
۲,۵,۶	Wiring of Analog input.....	۲۱
۲,۶	Port definition and wiring of encoder terminal (CN ^۲)	۲۲
۲,۶,۱	Motor encoder	۲۲
۲,۷	Definition of Communication Terminal (MINI USB).....	۲۳
۲,۷,۱	Communication terminal (MINI USB).....	۲۳
۲,۸	Wiring diagram in control mode	۲۴
3	Keypad Display and Operations.....	۳۷
4	Fault and Warning	۳۸
5	Parameter List	۴۲

1 Specification and Installation

1.1 Model Number

NG_①_②A - P R ④R₅ S₂

①: Serial number

NG1..A Series

③: Motor Type

R: Rotary servo motors

⑤: Voltage class S₂:

Single/Three phase 220V T₃:
Three phase 230V

②: Product category

P: Pulse/Analog/RS485

④: Rating

Single phase 220V	..1	1R1	2R8	5R0	7R1
Cont [A rms]	1.0A	1.6A	2.8A	5.0A	7.6A
Cont [P w]	100W	200W	400W	700W	1000W

Single/Three phase 220V	.12	.14
Cont [A rms]	11.6A	14.0A
Cont [P w]	1000W	2000W

Three phase 230V	2R0	5R2	8R2
Cont [A rms]	3.0A	5.5A	8.5A
Cont [P w]	100W	100W	200W

1.2 Electrical Specifications

Physical Dimensions	SIZE-A			SIZE-B		SIZE-C					
	NG1..A	..1S2	1R1S2	2R8S2	5R0S2	7R1S2	.12S2	.14S2	2R0T2	5R2T2	8R2T2
Continuous output current Arms	1.0	1.6	2.8	5.0	7.6	11.6	14.0	23.0	55.0	85.0	115.0
Maximum output current Arms	2.9	5.8	10.1	17.9	23.0	32.0	42.0	55.0	11.0	14.0	20.0
Continuous input current Arms	1.3	2.3	4.4	7.9	9.7	Single phase 115V Three phase 208V	Single phase 115V	Single phase 115V	2.4	3.7	6.7
Power supply of main circuit	Single phase AC 115V~230V -10%~+10%, 50/60Hz						Single /Three phase AC 115V~230V -10%~+10%, 50/60Hz	Three phase AC 230V~400V -10%~+10%, 50/60Hz			
Brake release function ¹	No Built-in regenerative resistor			Optional 50Ω/10W	Optional 100Ω/10W			Optional 100Ω/10W			

Note¹: HR²-PR Serial support External regenerative resistor²。


1.1 General Specifications

Item		Description	
Basic specifications	Control mode		IGBT SVPWM control, sine wave current drive mode 220V, 380V: Single/Three-phase full bridge rectification.
	use Conditions	Use/Storage temperature	-20~+70°C / -20~+70°C
		Use /Storage humidity	Below 90% RH (without condensation)
		Vibration/Impact resistance	±1.0m/s ² / 10.0m/s ²
		IP rating	IP20
	Pollution degree		PD0
	Altitude		Maximum altitude: 0~1000m. For altitudes lower than or equal to 1000m, derating is not required. For altitudes above 1000m but lower than 2000m, derate 1% for every additional 100m. For altitudes above 2000m, please contact the manufacturer.
Position control mode	Performance	Shaping of instructions	Position instruction low-pass filtering, mean filtering
		Feed forward compensation	Support speed feedforward (-1~100%) setting, eliminate follow up deviation.
	Frequency division output	Output mode	Phase A, phase B, phase Z: differential output
		Frequency division range	The motor rotates one circle, and the frequency can be divided into any pulse in the range of 100 to 1000000.
Speed/Torque control mode	Performance	current loop	Step Response Time: 180,0μs (-100%) Frequency response: -3dB (Amplitude attenuation bandwidth), 1000Hz (Reference Command: ±10%); -10% (Phase shifted bandwidth), 1000Hz (Reference Command: ±10%).
		Speed control range	-100~1000000rpm, If the speed exceeds 1000000rpm, please contact the manufacturer.
		Speed loop	Step Response Time: 60,0μs (-1000rpm) Frequency response: -3dB (Amplitude attenuation bandwidth), 100Hz (Reference Command: ±1000rpm); -10% (Phase shifted bandwidth), 100Hz (Reference Command: ±1000rpm)
		Torque control accuracy	±1%
Digital Input/output signals	Digital input signal	Function configurable: positive limit switch, negative limit switch, HomeSwitch, etc	
	Digital output signal	Function configurable: Servo ready, zero speed signal, speed arrival, position arrival, positioning approach signal, torque limit medium, warning, servo failure, etc.	
Built-in functions	Electronic gear ratio	Built-in two sets of electronic gear ratio, support gear ratio switching function	
	Overtravel (OT) prevention	The servo drive stops immediately at P-OT or N-OT actions.	
	Protections	Overcurrent, overvoltage, undervoltage, overload, main circuit detection abnormal, heatsink overheating, overspeed, encoder abnormal, parameter abnormal, etc.	
	display function	5-digit LED display, Main power CHARGE indicator	
	Debug interface	USB	
	vibration suppression	Four notches, 0.1Hz~100Hz, four of which are self-adaptive.	
	usability	Self-tuning, velocity observer, model tracking.	
Others		Status display, alarm record, JOG running, etc.	


Note 1: Please install the servo driver at ambient temperatures in this range.

1.4 Installation Dimensions


SIZE-A:



SIZE-B:



SIZE-C:



PROLINECNC

2 Wiring

1.1 Servo System Wiring Diagram




Figure 2-1 Layout diagram of the SIZE-A system

- Please use a circuit breaker with leakage protection and a noise filter between the power supply and the main power supply terminals;
- The voltage and power of the holding brake power supply must meet the requirements of the motor holding brake parameters;
- When SIZE-A does not have a built-in regenerative resistor and requires the use of an external regenerative resistor, please select the appropriate resistor. Do not exceed the minimum external resistance value allowed in Table 1-1, otherwise it may cause damage to the driver.




Figure2-2 Layout diagram of the SIZE-B system

- Please use a circuit breaker with leakage protection and a noise filter between the power supply and the main power supply terminals;
- The voltage and power of the holding brake power supply must meet the requirements of the motor holding brake parameters;
- When SIZE-B does not have a built-in regenerative resistor and requires the use of an external regenerative resistor, please select the appropriate resistor. Do not exceed the minimum external resistance value allowed in Table 1-1, otherwise it may cause damage to the driver.




Figure 2-3 Layout diagram of the SIZE-C system

- Please use a circuit breaker with leakage protection and a noise filter between the power supply and the main power supply terminals;
- The voltage and power of the holding brake power supply must meet the requirements of the motor holding brake parameters;
- When SIZE-C does not have a built-in regenerative resistor and requires the use of an external regenerative resistor, please select the appropriate resistor. Do not exceed the minimum external resistance value allowed in Table 1-1, otherwise it may cause damage to the driver.

1.1 Wiring of the Main Circuit

1.1.1 Main Circuit Terminals

Table 1-1 SIZE-A/B main circuit connecting terminal definition



Junctor	Terminal number	Terminal label	Terminal function	Description
	1	L1	Main power input	Single-phase AC 100V~240V, -10%~+10%, 50/60Hz
	2	L2		
	3	P	Regeneration function	If an external regenerative resistor is needed, connect it between terminals P and B.
	4	B		
	5	N	Motor Drive	Connected to U, V, W and PE phases of the servo motor.
	6	U		
	7	V		
	8	W		
	9	PE		

Table 1-2 SIZE-C main circuit connecting terminal definition

Junctor	Terminal number	Terminal label	Terminal function	Description
	1	L1	Main power input	Single/Three-phase AC 100V~240V, -10%~+10%, 50/60Hz
	2	L2		
	3	L3		
	4	P	Regeneration function	If an external regenerative resistor is needed, connect it between terminals P and B.
	5	B		
	6	N	Motor Drive	Connected to U, V, W and PE phases of the servo motor.
	7	U		
	8	V		
	9	W		
	10	PE		

2.2.2 Circlip type terminal connection method

The power terminal uses a circlip connector for quick connection. When connecting the power terminal, follow the following flowchart to ensure reliable connection.




Figure 2-4 Circlip type terminal connection method

- Peel off the insulation layer of the wire, with a bare wire length of 10mm.
- Press the operating lever to release the internal spring.
- Insert all bare wires into the connector.
- Release the operating lever, gently pull the wire to confirm secure connection, and then complete the wiring.

2.2.3 Specifications of Main Circuit Cables

Table 2-3 Recommended main circuit cables

SIZE	Model	L ₁ 、L ₂ 、L ₃		P、B		U、V、W		PE	
		mm ²	AWG	mm ²	AWG	mm ²	AWG	mm ²	AWG
Single-phase 220V									
SIZE-A	..1S2	2X0.75	18	2X0.75	18	2X0.75	18	0.75	18
	1R1S2	2X0.75	18	2X0.75	18	2X0.75	18	0.75	18
	2RAS2	2X0.75	18	2X0.75	18	2X0.75	18	0.75	18
SIZE-B	0R0S2	2X0.75	18	2X0.75	18	2X0.75	18	0.75	18
	VR1S2	2X1.00	17	2X1.00	17	2X1.00	17	1.00	17
SIZE-C	..12S2	2X1.00	10	2X1.00	10	2X1.00	10	1.00	10
	..14S2	2X2.00	12	2X2.00	12	2X2.00	12	2.00	12
Three-phase 220V									
SIZE-C	..12S2	3X1.00	17	2X1.00	10	2X1.00	10	1.00	10
	..14S2	3X1.00	10	2X2.00	12	2X2.00	12	2.00	12
Three-phase 380V									
SIZE-C	2R0T2	2X0.75	18	2X0.75	18	2X0.75	18	0.75	18
	0R2T2	2X0.75	18	2X0.75	18	2X0.75	18	0.75	18
	4R2T2	2X0.75	18	2X1.00	17	2X1.00	17	1.00	17

2.2 Wiring of the regenerative resistor

2.2.1 Wiring of external regenerative resistor




Figure2-5 Wiring of external regenerative resistor

- If an external regenerative resistor is needed for these models, please select the appropriate resistor. Do not exceed the min external resistance value allowed in Table 2-2, otherwise it may cause damage to the driver;
- External regeneration resistor connected between P and B;
- Do not connect the regeneration resistor to busbar P between N, otherwise it may cause damage to the drive and trigger a fire;
- Before using the servo, please confirm that the relevant parameters of the external regeneration resistor have been correctly set: P.2.34 (regeneration resistor type) , P.2.39 (power of external regenerative resistor) , P.2.40 (resistance of external regeneration resistor).

2.2.2 Regenerative resistor specifications

Table2-4 Regenerative resistor specifications

Servo driver Rated voltage and current	Min resistance of external resistor	Max braking energy absorbed by capacitance EC
Single phase 220V	1.0A	0.1Ω
	1.1A	0.1Ω
	2.8A	1.0Ω
	5.0A	1.0Ω
	7.6A	2.0Ω
Single/three phase 220V	12A	10Ω
	14A	10Ω
Three phase 380V	3.0A	8.0Ω
	5.5A	6.0Ω
	8.5A	4.0Ω

1.4 Wiring of the brake




Figure 2-6 Application of the motor brake

The brake is used to prevent the servo motor shaft from moving when the servo drive is in the non-operational status. This is to keep the motor and the mechanical load in locked positions.




Figure 2-7 Wiring of the brake


- The built-in brake in the servo motor is only used for position-lock purpose. Frequent use of the motor brake for emergency stop operations will shorten its service life. Only when the speed of the servo motor is less than 1·rpm, use this brake for position-lock in the stop state;
- It is recommended to use an independent power supply for the brake to prevent voltage drop caused by abnormalities in other electrical appliances, which may cause the brake to malfunction;
- Use a single power supply to the brake and brake control signals, avoid electromagnetic interference with electronic devices.

PROLINECNC

2.0 Port definition and wiring of control terminal (CN1)

2.0.1 Port definition of control terminal (CN1)

Table 2-0 Control signal CN1 port definition


IF interface connector (CN1)	Module Name	Signal Name	Pin No	Default Function
	Digital input	DI1	1	Positive limit
		DI2	10	Negative limit
		DI3	14	Origin switch
		DI4	8	Servo enable
		DI5	22	Fault reset
		DI6	22	Position deviation clearance
		DI7	21	Zero speed hold
		DI8	20	No definition
	Digital output	COM+	11	Common terminal of DI terminals
		DO1+	7	Brake control
		DO1-	6	
		DO2+	5	Servo running
		DO2-	4	
		DO3+	3	Servo fault output
		DO3-	2	
		DO4+	1	Position reached
	Frequency division output	DO4-	21	
		DO5+	28	Zero return completed
		DO5-	27	
		PAO+	21	A-phase frequency division output signal
		PAO-	22	
		PBO+	20	B-phase frequency division output signal
		PBO-	23	
		PZO+	13	Z-phase frequency division output signal
		PZO-	24	
		OCZ	24	Z-phase open collector output signal

Wiring

IF interface connector (CN1)	Module Name	Signal Name	Pin No	Default Function
Position reference		GND	29	Frequency division output signal ground
		PULSE+	41	Low speed pulse reference input
		PULSE-	43	
		SIGN+	37	
		SIGN-	39	
		PULLHI	30	Power input for pulse reference
		HPULSE+	38	High speed pulse reference input
		HPULSE-	36	
		HSIGN+	42	High speed position reference sign
		HSIGN-	40	
Analog input		AI1	20	Analog input signal 1
		AI2	18	Analog input signal 2
		GND-AI	16	Analog input signal ground
		GND-AI	19	Analog input signal ground
	+24V	17	+24V output power supply	
24V output power supply	COM-	14		
	PE	—	Shield layer	

PROLINECNC


4.5.2 Wiring of Digital input




PROLINECNC

(1) The host controller provides relay output

a) When using the internal $12V$ power supply:




b) When using an external power supply:




PROLINECNC

(r) The host controller provides open-collector output

a) When using the internal $12V$ power supply:




b) When using an external $12V$ power supply:



➤ PNP and NPN input cannot be used together in the same circuit.

PROLINECNC

4.5.3 Wiring of Digital output




- The maximum permissible voltage and current capacity of the optocoupler output circuit inside the servo drive are as follows:
 - Maximum voltage: DC 30V;
 - Maximum current: DC 5mA;


PROLINECNC

(1) The host controller provides relay input

- Correct wiring:




- Incorrect wiring:




PROLINECNC

(2) The host controller provides optocoupler input:

- Correct wiring:



- Incorrect wiring:



PROLINECNC

¶, ⑤, ⑥, ⑦ **Wiring of encoder frequency division output signals**




Figure2-8 Wiring of encoder frequency division output signals


- Please use an RS422 line receiver (AM26C32 or equivalent) to receive the pulse output signal;
- The maximum output current is 20mA;
- Use shielded twisted pairs to connect PE, and connect the GND of the receiver to the GND of the frequency division output signal

PROLINECNC

4.5.0 Wiring of position reference input signals

(1) Low speed pulse reference input

1) Differential mode





PROLINECNC

Wiring

1) Open collector mode


a) When using the internal $12V$ power supply:

- Correct wiring:



- Incorrect wiring:

Pin Y^1 (COM -) is not connected, leading to failure in forming a closed-loop circuit.





PROLINECNC

Wiring


b) When using an external $\pm 12V$ power supply:

- Correct wiring:

Scheme 1: Using the built-in resistor



Scheme 1: Using the external resistor



Select resistor R^1 based on the following formula : $\frac{V_{cc}-1.5}{R^1+240} = 1 \cdot \text{mA}$


Table 1-1 Recommended resistance of R^1

Vcc voltage	R^1 resistance	R^1 power
5V	1.5kΩ	0.05kΩ
12V	1.0kΩ	0.05kΩ

Wiring


- Incorrect wiring ①:

The current limiting resistor is not connected, resulting in terminal burnout.




- Incorrect wiring ②:

Multiple terminals share the same current limiting resistor, resulting in pulse receiving error.




- Incorrect wiring τ :

The SIGN port is not connected, preventing these two ports from receiving pulses.




- Incorrect wiring ε :

Terminals are connected incorrectly, resulting in terminal burnout.



- Incorrect wiring ◉:


Multiple terminals share the same current limiting resistor, resulting in pulse receiving error.



PROLINECNC

(2) High speed pulse reference input

High-speed reference pulses and signs on the host controller side can be outputted to the servo drive through the differential drive only.



NOTE:

- Please ensure that the differential input is a \circ V system, otherwise the input pulse of the servo drive will be unstable. This can lead to the following situations:
- When inputting pulse reference, there is a phenomenon of pulse loss;
- When inputting instruction direction, there is a phenomenon of instruction reversal;
- Please make sure to connect the \circ V system ground of the host device to the GND of the servo driver to reduce noise interference.

PROLINECNC

2.5.6 Wiring of Analog input

The input terminal for analog speed and torque signals is AI¹ and AI².

- Voltage input range: -10V~+10V;
- Maximum permissible voltage: $\pm 12V$;
- Input impedance: approx. $1k\Omega$.




Figure2-9 Analog Input Wiring Diagram

PROLINECNC

2.6 Port definition and wiring of encoder terminal (CN1)

2.6.1 Motor encoder

Table 2-5 Definition of the motor encoder interface

Motor encoder CN1	Signal Name	Pin No	Wiring method	Function
	0V	1		
	GND	2	Twisted pair	0V power supply
	—	3		—
	—	4		—
	SD+	5		
	SD-	6	Twisted pair	Encoder signal
	PE	enclosure	Shield layer	shield

- This terminal is used for the connection of the driver and the motor encoder, the cable and the main circuit wiring need to be 30cm away during use;
- Use a twisted pair shielded cable of 26AWG or above according to UL2464 for encoder cable;
- The encoder cable length needs to consider the voltage drop caused by line resistance and signal attenuation caused by distributed capacitance, and the recommended cable length is within 10m.





Figure 2-10 Motor encoder signal input

1.1 Definition of Communication Terminal (MINI USB)

1.1.1 Communication terminal (MINI USB)


Table 1-1 Definition of communication terminal MINI USB

Communication Terminal	Signal Name	Pin No	Function
	VBUS	1	PC communication
	D-	2	
	D+	3	
	—	4	
	GND	5	
	PE	Enclosure	


- This terminal is a commissioning port connected with the PC. Supports online trial operation and download and upload of parameters, and driver firmware update ex.

PROLINECNC

1.1 Wiring diagram in control mode



- Internal +V_t power supply, voltage range: 10 to 18 V, maximum output current: 100 mA.
- Use the shielded twisted pair as the cables of the pulse terminals, with both ends of the shielded layer tied to PE. Connect GND to the signal ground of the host controller reliably.
- A user needs to provide the power supply for DOs, with voltage range 0 to 5 V. The DO terminals support 10 VDC voltage and 10 mA current to the maximum.
- Use the shielded twisted pair as the encoder frequency-division cables, with both ends of the shielded layer tied to PE. Connect GND to the signal ground of the host controller reliably.



- Internal $\pm V$ power supply, voltage range: ± 10 V, maximum output current: 100 mA.
- Use the shielded twisted pair as the cables of the pulse terminals, with both ends of the shielded layer tied to PE. Connect GND to the signal ground of the host controller reliably.
- A user needs to provide the power supply for DOs, with voltage range $0 \sim 24$ V. The DO terminals support 10 VDC voltage and 100 mA current to the maximum.
- Use the shielded twisted pair as the encoder frequency-division cables, with both ends of the shielded layer tied to PE. Connect GND to the signal ground of the host controller reliably.




Figure 2-13 Wiring diagram in torque mode

- Internal $+\text{V}_{\text{DC}}$ power supply, voltage range: 10~V to 18~V , maximum output current: 100~mA .
- Use the shielded twisted pair as the cables of the pulse terminals, with both ends of the shielded layer tied to PE. Connect GND to the signal ground of the host controller reliably.
- A user needs to provide the power supply for DOs, with voltage range 5~V to 24~V . The DO terminals support 10~VDC voltage and 100~mA current to the maximum.
- Use the shielded twisted pair as the encoder frequency-division cables, with both ends of the shielded layer tied to PE. Connect GND to the signal ground of the host controller reliably.

3 Keypad Display and Operations

- The keypad of the drive consists of a 5-digit, 7-segment LED screen .
- The keypad is used for value display, parameter setting, user password setting and general function execution.





Figure3-1 Functions of keys

Ex: Use panel keys to jog at a speed of 1000rpm.



4 Fault and Warning

Fault Code	Fault Name	Fault Cause	Solution Measure
E.010..	Software Parameter Fault	1. Upgraded the new firmware. 2. Wrote abnormal parameters	Restore factory parameters (P.011=1) and check if the "manufacturer parameters" are abnormal.
E.012.X	Software Internal Interrupt Timeout Fault	1. FPGA fault. 2. Internal hardware abnormality	Replace the servo drive.
E.010.X	Current Sampling Timeout Fault	1. Power line output disconnection or poor contact. 2. Current sampling fault.	1. Check the Power line connection for damage. 2. Replace servo drive.
E.018.X	Parameter Out of Range Fault	1. Software has been updated 2. EEPROM fault.	1. Restore factory parameters (P.011=1) and check if the "manufacturer parameters" are abnormal. 2. Replace servo drive.
E.019.X	Product Matching Fault	1. Product number (encoder or motor or drive) does not exist. 2. The rated current of the motor is greater than the rated current of the driver.	1. Set the correct encoder type (P.010=1). 2. Replace with a higher power driver.
E.011.X	Hardware Overcurrent Fault	1. Driver fault. 2. The motor is burnt out. 3. Unreasonable gain parameter settings and motor vibration Dang.	1. Replace the drive. 2. Replace the motor. 3. Perform gain adjustment again.
E.011.X	Ground Short Circuit Fault	1. Short circuit between the motor and ground. 2. Servo drive fault. 3. The main line voltage release point (P.011) is set too low.	1. Check the insulation of the drive power cable. 2. Replace the drive. 3. Correctly set the main line voltage release point (P.011).
E.012..	UVW Phase Sequence Error	The UVW phase sequence of the driver and motor does not match.	Correctly connect the UVW cables in the right phase sequence.
E.012..	Overcurrent Fault	1. Incorrect UVW phase sequence wiring. 2. incorrect initial rotor phase of the motor. 3. The vertical axis is overloaded.	1. Correctly connect the UVW cables in the right phase sequence. 2. Redo the angle self-learning. 3. Reduce the vertical axis load or shield the fault without compromising safety.
E.011.X	Encoder Parameter Fault	1. The type of the driver and motor do not match. 2. Parameter error or not stored in encoder.	1. Set the correct motor type. 2. Write the correct motor parameters.
E.011.X	Encoder Communication Fault	1. Encoder wiring error. 2. Encoder cable loose. 3. Encoder signal interference (related to EMC issues).	1. Reconnect according to the correct wiring diagram. 2. Ensure tight connection of encoder wiring terminals. 3. Use our standard encoder cable.
E.012..	Encoder Parameter Verification Error	1. Encoder disconnected or loose. 2. Encoder parameter read/write abnormality.	1. Check the encoder wiring. 2. Rewrite the motor parameters.

Fault and Warning

Fault Code	Fault Name	Fault Cause	Solution Measure
E.Y11..	Driver Overtemperature Fault	1. After the overload is cleared, the drive runs repeatedly. 2. Fan damaged.	1. wait 2+ seconds after overload before resetting, deceleration times and reduce the load. 2. Check the fan.
E.Y11.X	DI Function Allocation Fault	1. DI function number exceeds. 2. Duplicate DI Function Assignment.	1. After restoring system parameters to default (P.0.1=1), power on again. 2. Do not assign DI function numbers beyond the DI function definition table.
E.Y12..	DO Function Allocation Fault	DO function number exceeds.	Do not assign DO function numbers beyond the DO function definition table.
E.Y14..	DC Bus Undervoltage Fault	1. Momentary power outage occurs. 2. Voltage drop in power supply during operation. 3. Three phase input only connected to single-phase	Check the input power supply.
E.Y15..	DC Bus Overvoltage Fault	1. Main circuit input voltage too high. 2. The motor is in a rapid deceleration state, and the brake resistor has failed.	1. Check the input power supply. 2. Replace the brake resistor.
E.Y16..	Overspeed Fault	1. Incorrect phase sequence of motor cables U, V, W. 2. Incorrect motor or encoder parameter settings. 3. Initial angle identification error of motor. 4. Motor speed closed-loop overshoot.	1. Wire the U, V, W phases correctly. 2. Set motor parameters or encoder resolution correctly. 3. Re angle identification. 4. Perform gain adjustment again.
E.Y11.X	Inertia Identification Fault	Offline inertia identification is not completed.	Contact the manufacturer's technical support.
E.Y12..	Pole Identification Fault	Failure in identifying the initial magnetic pole angle of the motor.	Disconnect the motor shaft and re-identify the angle.
E.B11..	Motor Overload Fault	1. The processing cycle is frequent, the acceleration and deceleration time is set too short, and the load is too heavy. 2. The motor power model has been selected too small.	1. Reduce processing speed and increase acceleration and deceleration time. 2. Replace with a higher power motor.
E.B11..	Motor Stall Fault	1. Incorrect phase sequence of motor cables U, V, W. 2. Motor angle error. 3. The encoder communication protocol (P.1..) is set incorrectly. 4. Motor stalling caused by mechanical factors, resulting in excessive load during operation.	1. Wire the U, V, W phases correctly. 2. Re angle identification. 3. Set the correct P.1.. parameter. 4. Check the mechanical structure.
E.011.X	Parameter Storage Fault	Abnormal storage of drive parameters	1. After restoring initialization (P.0.1=1), set P.01.1=1. 2. Replace servo drive.
E.Y17.X	Input Phase Loss Fault	1. Three-phase drive connected to single-phase input. 2. Poor wiring of three-phase input. 3. Unbalanced or low three-phase voltage.	1. Connect three-phase input power supply. 2. Check the three-phase power supply wiring. 3. For three-phase rated drives that allow single-phase operation (below 1kW), disable alarms (set P.1..=1).
E.Y18..	Servo Emergency Stop Fault	Emergency stop triggered.	Under the premise of confirming safety, the emergency stop function can be released (emergency stop release, automatic reset of

Fault and Warning

Fault Code	Fault Name	Fault Cause	Solution Measure
			emergency stop fault)
E.222.X	Output Phase Loss Fault	1. Motor U or V or W phase power line disconnected. 2. Hardware damage	1. Check the motor power cable connection. 2. Replace the drive.
E.111.X	Servo Repeated Enable Fault	When the servo is internally enabled, it is externally repeatedly enabled.	Close the internal enable of the servo.
E.111..	Driver Overload Fault	1. The processing cycle is frequent, the acceleration and deceleration time is set too short, and the load is too heavy. 2. The power model of the driver has been selected too small.	1. Reduce processing speed and increase acceleration and deceleration time. 2. Replace with a higher power driver.
E.111.X	Electronic Gear Ratio Setting Error	The set value of electronic gear ratio exceeds the range.	Set the gear ratio according to the range of the electronic gear ratio.
E.111.X	Excessive Position Deviation Fault	1. The U, V, W outputs of the driver lack phase or disconnection. 2. The encoder is inserted incorrectly. 3. Motor stalling due to mechanical factors. 4. The gain of the servo drive is low. 5. The incremental position command is too large. 6. The deviation threshold 1.10h/P.1.1 is too small.	1. Check the UVW output cable. 2. Check the encoder cable. 3. Investigate mechanical factors. 4. Perform manual or automatic gain adjustment. 5. Increase the acceleration and deceleration ramps of the position command. 6. Increase the deviation threshold 1.10h/P.1.1.
E.111.X	Position Command Overspeed Fault	1. The position command increment received by the servo is too large. 2. The motor speed limit is set incorrectly.	1. Decrease the target position command increment. 2. Set the planned speed of the upper computer to be less than the maximum speed of the motor.
E.111..	Encoder Battery Fault	1. Absolute encoder is not connected to the battery. 2. Encoder battery voltage is too low.	1. Reconnect the battery or replace it with a new one. 2. Set P1.1.1=1 to clear the fault.
E.111..	Encoder Multi-turn Counting Error	Encoder internal fault.	Set P1.1.1=1 to clear the fault and power on again. If the fault cannot be eliminated, the motor needs to be replaced.
E.111.X	Encoder multi turn counter overflow fault	The multi circle data is 32767 or 32768.	Set P1.1.1=1 to clear the encoder's multi turn data and power on again.
E.B11..	Motor Vibration Fault	Motor vibration occurs	1. Adjust the gain parameters. 2. Enable vibration suppression.
E.D11.X	EtherCAT Communication Abnormality	1. When the servo is enabled, the EtherCAT network switches out of the OP state. 2. The synchronization signal SYNC is abnormal.	Check the upper computer network status switching program. Contact manufacturer technical support.
E.D11..	EtherCAT XML File Not Burned	1. The XML file has not been burned. 2. The internal XML file of the drive is damaged.	Re burn the XML file.
E.D11..	EtherCAT Sync Period Setting Error	Synchronization period setting error.	The synchronization period needs to be set as an integer multiple of the position loop period (10.us).

Fault and Warning

Fault Code	Fault Name	Fault Cause	Solution Measure
E.D**.·	EtherCAT Sync Signal Deviation Too Large	Sync period error value exceeds the threshold	Increase the synchronization deviation threshold (P·A**).
A.**.·	Positive Travel Exceeding Warning	Positive limit input active	Under confirmed safety, give the motor a negative command to invalidate the forward limit.
A.**1.·	Negative Travel Exceeding Warning	Negative limit input active	Under confirmed safety, give the motor a forward rotation command to invalidate the negative limit.
A.**2.·	Input Phase Loss Warning	Missing phase in three-phase power input.	<ul style="list-style-type: none"> 1. Check the three-phase power supply connection. 2. For three-phase rated drives that allow single-phase operation (below 1 kW), disable alarms (set P·A**=2).
A.**3.·	Regenerative Resistor Overload Warning	<ul style="list-style-type: none"> 1. Regeneration resistor is not connected or connected incorrectly. 2. The power of the connected regenerative resistor is too low. 3. Incorrect parameter settings for regenerative resistors: type, resistance, power, etc. 	<ul style="list-style-type: none"> 1. Check the wiring of the regeneration resistor. 2. Replace with a higher power regeneration resistor. 3. Set the regeneration resistor parameters correctly.
A.**.X	Regenerative Resistor Not Connected Warning	No regeneration resistor connected.	Refer to the user manual to check the connection of the regeneration resistor.
A.**4.·	Regenerative Resistor Not Connected Warning	The value of the external regeneration resistor is less than the minimum allowable value specified in the specifications.	Correctly set the parameters related to the external regeneration resistor.
A.**5.·	Origin Return Timeout Warning	<ul style="list-style-type: none"> 1. The itinerary is too long, and the time limit for finding the origin is too short. 2. The speed of searching for the origin switch signal is too slow. 3. Switch abnormality: Positive limit or negative limit or origin switch are simultaneously activated or the switch signal cannot be detected. 	<ul style="list-style-type: none"> 1. Increase the origin search time P1**4. 2. Increase the homing high speed 1.**-1h. 3. Check the switch signal.
A.**6.·	Require Reboot Warning	Modified the parameters that need to be re-powered on to take effect.	Power on again or reset the software.
A.**7.·	Encoder Battery Low Voltage Warning	The voltage of the absolute value encoder battery is below 2.0V	Check the power supply cable of the encoder or replace it with a new battery.
A.D**.·	Zero Return Method Setting Error Warning	The reset method is set incorrectly.	Correctly set 1.**h (does not support zeroing methods such as 10/16/31/12).

Note:

1. The 'X' in the fault code represents a sub fault code;

5 Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
• Motor Parameters						
P...3	Motor SN	-	~60030	UINT16	•	At stop
P..10	Rated voltage	V	~220V	UINT16	•	At stop
P..11	Rated current	..A	~60030	UINT16	470	At stop
P..12	Rated power	..kW	~60030	UINT16	70	At stop
P..13	Rated torque	..Nm	~4294967290	UINT32	229	At stop
P..17	Rated speed	rpm	~60030	UINT16	3000	At stop
• Encoder Parameters						
P.1..	Bus encoder type	-	~60030	UINT16	11223	At stop
P.1.3	Encoder version	-	~60030	UINT16	•	Unchangeable
P.1.0	Customized No.	-	~4294967290	UINT32	1048076	At stop
• Servo Drive Parameters						
P.2..	MCU software version	-	~60030	UINT16	•	Unchangeable
P.2.1	FPGA software version	-	~60030	UINT16	•	Unchangeable
P.2.2	MCU Customized No.	-	~4294967290	UINT32	•	Unchangeable
P.2.4	FPGA Customized No.	-	~4294967290	UINT32	•	Unchangeable
P.212	Voltage class	-	~60030	UINT16	220	Unchangeable
P.213	Rated power	..kW	~60030	UINT16	70	Unchangeable
P.210	Rated current	..A	~60030	UINT16	000	Unchangeable
P.234	Regenerative resistor type	-	~- Built-in	UINT16	•	At stop
			1- External, natural ventilated			
			2- External, forced air cooling			
			3- Not needed			
P.230	Resistor heat dissipation coefficient	-	1~1...	UINT16	30	At stop
P.236	Power of built-in regenerative resistor	W	1~60030	UINT16	40	Unchangeable
P.237	Resistance of builtin regenerative resistor	Ω	1~1...	UINT16	00	Unchangeable
P.238	Min.Resistance of external regenerative resistor	Ω	1~1...	UINT16	40	Unchangeable
P.239	Power capacity of external regenerative resistor	W	1~60030	UINT16	40	At stop
P.240	Resistance of external regenerative resistor	Ω	1~1...	UINT16	00	At stop
• IO Parameters						
P.3..	DI1 function	-	~- null	UINT16	9	At stop
			1-SON			
			2- Emergency stop			

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
			٢- Position reference inhibited ٣- ClrPosErr ٤- ALM-RST ٥- ZCLAMP ٦- JOGCM+ ٧- JOGCM- ٨- P-OT ٩- N-OT ١٠- HomeSwitch ١١- HomingStart ١٢- speed limit source ١٣- Positive external torque limit ١٤- Negative external torque limit ١٥- Multi-position reference enable ١٦- Torque reference direction ١٧- Speed reference direction ١٨- Position reference direction ٢٠- Gain switchover switch ٢١- Switchover between main and auxiliary commands ٢٢- Mode switchover ١ ٢٣- Mode switchover ٢ ٢٤- Electronic gear ratio selection ٢٥- Multi-reference switchover ١ ٢٦- Multi-reference switchover ٢ ٢٧- Multi-reference switchover ٣ ٢٨- Multi-reference switchover ٤ ٢٩- Multi-reference switchover ٥ ٣٠- Multi-reference switchover ٦ ٣١- through DI in Home switch			
P.٣.١	DI١ logic selection	-	٠- Active low ١- Active high	UINT١٦	.	At stop
P.٣.٢	DI٢ function selection	-	See P.٣.٠	UINT١٦	٠	At stop
P.٣.٣	DI٣ logic selection	-	٠- Active low ١- Active high	UINT١٦	.	At stop
P.٣.٤	DI٤ function selection	-	See P.٣.٠	UINT١٦	١	At stop
P.٣.٥	DI٥ logic selection	-	٠- Active low ١- Active high	UINT١٦	.	At stop
P.٣.٦	DI٦ function selection	-	See P.٣.٠	UINT١٦	١	At stop
P.٣.٧	DI٧ logic selection	-	٠- Active low ١- Active high	UINT١٦	.	At stop
P.٣.٨	DI٨ function selection	-	See P.٣.٠	UINT١٦	٠	At stop
P.٣.٩	DI٩ logic selection	-	٠- Active low ١- Active high	UINT١٦	.	At stop

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
P.211	DI1 function selection	-	See P.200	UINT16	4	At stop
P.211	DI1 logic selection	-	•- Active low 1- Active high	UINT16	•	At stop
P.212	DI2 function selection	-	See P.200	UINT16	6	At stop
P.212	DI2 logic selection	-	•- Active low 1- Active high	UINT16	•	At stop
P.213	DI3 function selection	-	See P.200	UINT16	•	At stop
P.213	DI3 logic selection	-	•- Active low 1- Active high	UINT16	•	At stop
P.214	DI4 function selection	-	See P.200	UINT16	•	At stop
P.214	DI4 logic selection	-	•- Active low 1- Active high	UINT16	•	At stop
P.218	DI function allocation 1 (activated upon power-on)	-	•- null	UINT16	•	At stop
			1-SON			
			Y- Emergency stop			
			Y- Position reference inhibited			
			Y- ClrPosErr			
			Y- ALM-RST			
			Y- ZCLAMP			
			Y- JOGCM+D			
			Y- JOGCM-D			
			Y- P-OT			
			Y- N-OT			
			Y- HomeSwitch			
			Y- HomingStart			
			Y- speed limit source			
			Y- Positive external torque limit			
			Y- Negative external torque limit			
			Y- Multi-position reference enable			
			•- null			
P.219	DI function allocation 2 (activated upon power-on)	-	Y- Torque reference direction	UINT16	•	At stop
			Y- Speed reference direction			
			Y- Position reference direction			
			Y- Gain switchover switch			
			Y- Switchover between main and auxiliary commands			
			Y- Mode switchover 1			
			Y- Mode switchover 2			
			Y- Electronic gear ratio selection			
			Y- Multi-reference switchove 1			
			Y- Multi-reference switchove 2			
			Y- Multi-reference switchove 3			
			Y- Multi-reference switchove 4			
			Y- through DI in Home switch			
			•- null			
			•-rdy			
			•-Run			
P.221	DO1 function selection	-	•-null •-rdy •-Run	UINT16	17	At stop

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
			1-Warn 2-Alm 3-TGon 4-Zero 5-VCmp 6-VArr 7-TArr 8-(Near 9-Coin 10-Clt 11-Vlt 12-HomeOK 13-eHomeOK 14-BK 15-DB 16-AngRdy			
P.321	DO ¹ logic selection	-	0- Active low 1- Active high	UINT16	0	At stop
P.322	DO ² function selection	-	See P.320	UINT16	2	At stop
P.323	DO ³ logic selection	-	0- Active low 1- Active high	UINT16	0	At stop
P.324	DO ⁴ function selection	-	See P.320	UINT16	4	At stop
P.325	DO ⁵ logic selection	-	0- Active low 1- Active high	UINT16	0	At stop
P.326	DO ⁶ function selection	-	See P.320	UINT16	11	At stop
P.327	DO ⁷ logic selection	-	0- Active low 1- Active high	UINT16	0	At stop
P.328	DO ⁸ function selection	-	See P.320	UINT16	14	At stop
P.329	DO ⁹ logic selection	-	0- Active low 1- Active high	UINT16	0	At stop
P.330	Forced DI/DO selection	-	0- No operation 1- Forced DI enabled, forced DO disabled 2- Forced DO enabled, forced DI disabled 3- Forced DI and DO enabled	UINT16	0	Immediate
P.331	Forced DI setting	-	0~11	UINT16	011	Immediate
P.332	Forced DO setting	-	0~31	UINT16	0	Immediate
P.334	Communication Forced DO selection	-	0~7	UINT16	0	At stop
P.344	AI ¹ input filter time	0..1ms	0~60030	UINT16	200	Immediate
P.345	AI ² input filter enable	-	0~1	UINT16	1	Immediate
P.348	AI ³ input filter time	0..1ms	0~60030	UINT16	200	Immediate
P.349	AI ⁴ input filter enable	-	0~1	UINT16	1	Immediate
P.362	Speed corresponding to AI 1·V	rpm	0~6000	UINT16	2000	At stop

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
P.212	torque corresponding to AI 1·V	倍	..~8..	UINT16	1..	At stop
• Motion Control Parameters						
P.4..	Control Mode	-	.. Speed Control Mode	UINT16	1	At stop
			1- Position control mode			
			2- Torque Control Mode			
			3- Torque Control Mode -> Speed Control Mode			
			4- Speed Control Mode -> Position control mode			
			5- Torque Control Mode -> Position control mode			
			6- Torque Control Mode -> Speed Control Mode -> Position control mode			
P.4..	Forward direction	-	.. Counter-clockwise (CCW) as forward direction	UINT16	.	At stop
			1- Clockwise (CW) as forward direction			
P.4..	Absolute position detection system	-	.. Incremental position mode	UINT16	.	At stop
			1- Absolute position linear mode			
			2- Absolute position rotation mode			
P.4..	Stop mode at No.1 fault	-	.. Coast to stop, keeping deenergized state	UINT16	2	At stop
			1- DB stop, keeping de-energized state			
			2- DB stop, keeping DB state			
P.4..	Stop mode at No.2 fault	-	.. Coast to stop, keeping deenergized state	UINT16	2	At stop
			1- Stop at zero speed, keeping deenergized state			
			2- Stop at zero speed, keeping dynamic braking state			
			3- DB stops, keeping operation state			
			4- DB stop, keeping DB state			
P.4..	Stop mode at S-OFF	-	.. Coast to stop	UINT16	2	At stop
			1- DB stops			
			2- Stop at zero speed			
P.4..	Stop state at S-OFF	-	.. keeping operation state	UINT16	1	At stop
			1- keeping DB state			
P.4..	Stop mode upon main circuit power-off	-	..P.4..	UINT16	.	At stop
			1- Forced zero speed			
P.4..	Stop mode at overtravel	-	.. Coast to stop, keeping deenergized state	UINT16	1	At stop
			1- Stop at zero speed, keeping position lock state			
			2- Stop at zero speed, keeping deenergized state			
P.423	Torque at T-OFF	..,1%	..~3..	UINT16	1...	At stop
• Function Parameters						
P.0..	Manufacturer password	-	..~60030	UINT16	.	Immediate
P.0..	Parameter	-	.. No operation	UINT16	.	At stop

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
			1- Restore default settings			
P.010	Communication memory	-	0- Disabled	UINT16	1	Immediate
			1- Enabled			
P.011	Power-off memory	-	0- Disabled	UINT16	0	Immediate
			1- Enabled			
P.012	BK switch	-	0- Disabled	UINT16	1	At stop
			1- Enabled			
P.013	S-ON brake open delay	ms	0~500	UINT16	200	Immediate
P.014	S-ON brake zero speed time	ms	1~1000	UINT16	100	Immediate
P.015	S-ON brake speed	rpm	0~3000	UINT16	3000	Immediate
P.016	S-ON brake time	ms	1~1000	UINT16	500	Immediate
P.019	power-on test	-	0- Disabled	UINT16	1	At stop
			1- Enabled			
P.023	Output pulse phase	-	0-Phase A leads phase B	UINT16	0	At stop
			1-Phase A lags behind phase B			
P.043	Software limit selection	-	0-No operation	UINT16	0	At stop
			1-Activated immediately			
			2-Activated after homing is done			
• Gain Parameters						
P.100	Speed loop gain	0,1Hz	1~2000	UINT16	2000	Immediate
P.101	Speed loop integral time constant	0,01ms	10~10000	UINT16	3183	Immediate
P.102	Position loop gain	0,1Hz	0~2000	UINT16	400	Immediate
P.108	Speed feedforward gain	0,1%	0~100	UINT16	0	Immediate
P.109	Torque feedforward gain	0,1%	0~2000	UINT16	0	Immediate
P.110	Load moment of inertia ratio	-	0~1000	UINT16	200	Immediate
• Filter time Parameters						
P.700	Position FIR filter	0,1ms	0~60000	UINT16	0	At stop
P.701	Time constant of moving average filter	0,1ms	0~1280	UINT16	0	At stop
P.702	Torque filter 1	0,01ms	0~2000	UINT16	79	Immediate
P.706	Speed feedforward filter	0,01ms	0~6400	UINT16	0	Immediate
P.707	Torque feedforward filter	0,01ms	0~6400	UINT16	0	Immediate
P.711	Frequency of the 1st notch	Hz	0.00~100	UINT16	0	Immediate
P.711	Width level of the 1st notch	-	0~20	UINT16	2	Immediate
P.712	Depth level of the 1st notch	-	0~99	UINT16	0	Immediate
P.713	Frequency of the 2nd notch	Hz	0.00~100	UINT16	0	Immediate
P.714	Width level of the 2nd notch	-	0~20	UINT16	2	Immediate
P.715	Depth level of the 2nd notch	-	0~99	UINT16	0	Immediate
P.716	Frequency of the 3rd notch	Hz	0.00~100	UINT16	0	Immediate

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
P.717	Width level of the 1st notch	-	..~20	UINT16	2	Immediate
P.718	Depth level of the 1st notch	-	..~99	UINT16	1	Immediate
P.719	Frequency of the 1st notch	Hz	0..~8...	UINT16	0...	Immediate
P.720	Width level of the 2st notch	-	..~20	UINT16	2	Immediate
P.721	Depth level of the 2st notch	-	..~99	UINT16	1	Immediate
P.722	Frequency of the A notch	Hz	1..~1...	UINT16	1...	At stop
P.724	Low-speed filter	ms	..~200	UINT16	20	At stop
P.725	High-speed filter	ms	..~200	UINT16	2	At stop
P.726	speed reach filter	ms	..~8...	UINT16	10	At stop
• ⁸ Protection Parameters						
P.800	Power input phase loss protection	-	..- Enable phase loss fault 1- Enable phase loss fault and warning 2- Disabled	UINT16	1	Immediate
P.801	Encoder multi-turn overflow fault	-	..- Disabled 1- Enabled	UINT16	1	At stop
P.803	Runaway speed threshold	rpm	..~1...	UINT16	1	Immediate
P.808	Clear action	-	..- Clear position deviation upon SOFF 1- Clear position deviation upon SOFF and Clear position deviation by ClrPosErr signal input from DI	UINT16	1	At stop
P.809	Runaway protection	-	..- Disabled 1- Enabled	UINT16	1	Immediate
P.810	Runaway current threshold	..,1%	1...~4...	UINT16	2...	Immediate
P.811	Runaway speed threshold	rpm	1~1...	UINT16	10	Immediate
P.812	Runaway Speed feedback filtering time	..,1ms	1~1...	UINT16	20	Immediate
P.813	Runaway protection detection time	ms	1..~1...	UINT16	20	Immediate
P.814	Motor overload protection gain	%	0..~3...	UINT16	100	At stop
P.816	Motor overload detection	-	..- Disabled 1- Enabled	UINT16	1	At stop
P.817	Motor stall detection	-	..- Disabled 1- Enabled	UINT16	1	Immediate
P.818	Motor stall overtemperature protection time	ms	1..~60000	UINT16	200	Immediate
P.821	Over temperature threshold	°C	..~1...	UINT16	1	At stop
• ⁹ Display Parameters						
P.900	Position speed reference	rpm	-32767~32767	INT16	1	Unchangeable
P.901	Speed reference	rpm	-32767~32767	INT16	1	Unchangeable
P.902	torque reference	..,1%	-32767~32767	INT16	1	Unchangeable

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
P.913	Motor speed feedback	rpm	-32767~32767	INT16	.	Unchangeable
P.914	speed actual value	rpm	-32767~32767	INT16	.	Unchangeable
P.916	speed actual value (.,'1rpm)	rpm	-2147483648~2147483647	INT32	.	Unchangeable
P.917	Bus voltage	.1V	.~60030	UINT16	.	Unchangeable
P.918	Ctr voltage	.1V	.~60030	UINT16	.	Unchangeable
P.919	RMS value of phase current (U)	.01A	.~60030	UINT16	.	Unchangeable
P.9110	RMS value of line voltage	.1V	.~60030	UINT16	.	Unchangeable
P.9111	Average load rate	.1%	.~8...	UINT16	.	Unchangeable
P.9112	temperature	°C	.~60030	UINT16	.	Unchangeable
P.9113	Electrical angle	.1°	.~60030	UINT16	.	Unchangeable
P.9114	Monitored DI status	-	.~60030	UINT16	.	Unchangeable
P.9115	Monitored DO status	-	.~60030	UINT16	.	Unchangeable
P.9116	value of AI1 voltage	V	-32767~32767	INT16	.	Unchangeable
P.9117	value of AI2 voltage	V	-32767~32767	INT16	.	Unchangeable
P.9118	Total power-on time	.1s	.~4294967290	UINT32	.	Unchangeable
P.9119	Current power on time	-	.~4294967290	UINT32	.	Unchangeable
P.9120	Input position reference counter	Reference unit	-2147483648~2147483647	INT32	.	Unchangeable
P.9121	Position reference counter	Reference unit	-2147483648~2147483647	INT32	.	Unchangeable
P.9122	Position feedback counter	Reference unit	-2147483648~2147483647	INT32	.	Unchangeable
P.9123	Encoder Position feedback counter	Encoder unit	-2147483648~2147483647	INT32	.	Unchangeable
P.9124	position deviation counter	Reference unit	-2147483648~2147483647	INT32	.	Unchangeable
P.9125	Encoder position deviation counter	Encoder unit	-2147483648~2147483647	INT32	.	Unchangeable
P.9126	Number of revolutions recorded in the absolute encoder	Reference unit	.~60030	UINT16	.	Unchangeable
P.9127	Single-turn position fed back by the absolute encode	p	.~2147483647	UINT32	.	Unchangeable
P.9128	Absolute position fed back by the absolute encoder (low 32 bits)	Encoder unit	-2147483648~2147483647	INT32	.	Unchangeable
P.9129	Absolute position fed back	Encoder unit	-2147483648~2147483647	INT32	.	Unchangeable

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
	by the absolute encoder (high 32 bits)					
P.949	Mechanical absolute position (low 32 bits)	Encoder unit	-2147483648~2147483647	INT32	.	Unchangeable
P.950	Mechanical absolute position (high 32 bits)	Encoder unit	-2147483648~2147483647	INT32	.	Unchangeable
P.953	Load position within one turn in absolute position rotation mode (low 32 bits)	Encoder unit	.~4294967290	UINT32	.	Unchangeable
P.955	Load position within one turn in absolute position rotation mode (high 32 bits)	Encoder unit	.~4294967290	UINT32	.	Unchangeable
P.957	Load position within one turn in absolute position rotation mode	Reference unit	.~4294967290	UINT32	.	Unchangeable
• A Communication Parameters						
P.A..	Drive axis address	-	1~247	UINT16	1	Immediate
P.A.2	Serial baud rate	-	..2400bps	UINT16	7	Immediate
			1-4800bps			
			2-9600bps			
			3-19200bps			
			4-38400bps			
			5-57600bps			
			6-115200bps	UINT32		
P.A.3	Modbus data format	-	.. No parity, 2 stop bits (N-2)	UINT16	.	Immediate
			1- Even parity, 1 stop bit (N-E-1)			
			2- Odd parity, 1 stop bit (N-O-1)			
			3- No parity, 1 stop bit (N-1)			
• Position Control Parameters						
P12..	Torque Control Parameters	-	.. Pulse reference	UINT16	.	At stop
			1- Pulse reference			
P12.1	Pulses per revolution	1P/REV	.~1..48076	UINT32	.	At stop
P12.2	Electronic gear ratio 1 (numerator)	-	1~1.73741824	UINT32	1	Immediate
P12.0	Electronic gear ratio 1 (denominator)	-	1~1.73741824	UINT32	1	Immediate
P12.7	Condition for positioning completed signal output	-	.. Absolute position deviation lower than the setpoint of P12..8	UINT16	.	Immediate
			1- Absolute position deviation lower than the setpoint of P12..8 and the			

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
			filtered position reference is · `- Absolute position deviation lower than the setpoint of P12,18 and the unfiltered position reference is · `- Absolute position deviation kept lower than the setpoint of P12,18 within the time defined by P12,10 and the unfiltered position reference is ·			
P12,8	Threshold of positioning completed	Encoder unit	1~60030	UINT16	7	Immediate
P12,9	Proximity threshold	Encoder unit	1~60030	UINT16	60030	Immediate
P12,10	Hold time of positioning completed	ms	·~3....	UINT16	·	Immediate
P12,12	Speed feedforward control	-	·- No speed feedforward `- Internal speed feedforward `-AI1 `-AI2	UINT16	1	At stop
P12,13	Position pulse reference input terminal	-	·- Low speed `- High speed	UINT16	·	At stop
P12,14	Pulse reference form	-	·- Direction + Pulse, positive logic `- Direction + Pulse, negative logic `- Phase A + phase B quadrature pulse, quadrupled frequency `-CW+CCW	UINT16	·	At stop
P12,15	Servo pulse output source	-	·- Encoder frequency division output `- Pulse reference synchronous output `- Frequency division or synchronous output inhibited	UINT16	·	At stop
P12,16	Number of encoder frequency-division pulses	P/REV	30~1.73741824	UINT32	20..	At stop
P12,18	Position pulse edge	-	·- Falling edge-triggered `- Rising edge-triggered	UINT16	·	Immediate
P12,22	Encoder multi-turn data offset L22	Encoder unit	-2147483648~2147483647	INT32	·	At stop
P12,25	Encoder multi-turn absolute position NG22	Encoder unit	-2147483648~2147483647	INT32	·	At stop
P12,27	Mechanical gear ratio in absolute position rotation mode (numerator)	-	1~60030	UINT16	1	At stop
P12,28	Mechanical gear ratio in absolute	-	1~60030	UINT16	1	At stop

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
	position rotation mode (denominator)					
P1329	Mechanical position L ²²	Encoder unit	.~4294967290	UINT22	.	At stop
P1330	Mechanical position NG ²²	Encoder unit	.~4294967290	UINT22	.	At stop
P1344	homing function	-	•- Disabled 1-DI 2- real time	UINT16	.	Immediate
P1340	Homing mode	-	.~20	INT16	1	At stop
P1346	Speed of highspeed search for home switch signal	rpm	.~3000	UINT16	100	Immediate
P1347	Speed of lowspeed search for home switch signal	rpm	.~1000	UINT16	10	Immediate
P1348	Speed of lowspeed search for home switch signal	rpm/s	.~60030	UINT16	1000	Immediate
P1349	Home search time limit	s	.~600,30	UINT16	000,00	Immediate
P1351	Mechanical home offset	Reference unit	-1.73741824~1.73741824	INT32	.	Immediate
P1356	Mechanical torque limit	-	.~3000	UINT16	1000	Immediate
P1359	Electronic gear ratio switchover condition	-	•- position reference is kept 1- Switched in real time	UINT16	.	At stop
P1360	Positioning window time	ms	.~3000	UINT16	.	Immediate
P1363	Forward position of software limit	Reference unit	-2147483648~2147483647	INT32	2147483647	At stop
P1366	Reverse position of software limit	Reference unit	-2147483648~2147483647	INT32	-2147483648	At stop

14 Speed Control Parameters

P14..	Speed reference source	-	•- A	UINT16	.	Keyboard At stop
			1- B			
			2- A+B			
			3- Switched between A B			
			DI			
P14.1	Source of main speed reference A	-	4- Communication	UINT16	.	At stop
			•- keypad			
			1- Multi-speed			
			2-AI1			
			3-AI2			
P14.2	Source of main speed reference B	-	•- keypad	UINT16	1	At stop
			1- Multi-speed			
			2-AI1			
			3-AI2			
P14.3	Maximum speed limit	rpm	.~60000	UINT16	10000	Immediate
P14.4	Forward speed threshold	rpm	.~60000	UINT16	10000	Immediate

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
P14.0	Reverse speed threshold	rpm	..~1....	UINT16	1....	Immediate
P14.1	Jog speed setpoint	rpm	..~1....	UINT16	1..	Immediate
P14.2	Speed reference set through keypad	rpm	-9999~3....	INT16	2..	Immediate
P14.3	Acceleration ramp time constant of speed reference	ms	..~10030	UINT16	.	Immediate
P14.4	Deceleration ramp time constant of speed reference	ms	..~10030	UINT16	.	Immediate
P14.5	Zero clamp speed threshold	rpm	..~1...	UINT16	1.	Immediate
P14.6	Torque feedforward control	-	-- No torque feedforward 1- Internal torque feedforward	UINT16	1	Immediate
P14.7	Threshold of TGON (motor rotation) signal	rpm	..~1...	UINT16	2.	Immediate
P14.8	Threshold of VCmp (speed matching) signal	rpm	..~1...	UINT16	1.	Immediate
P14.9	Threshold of speed reach signal	rpm	1..~7...	UINT16	1...	Immediate
P14.10	Threshold of zero speed output signal	rpm	1~7...	UINT16	1.	Immediate
10 Torque Control Parameters						
P10.0	Torque reference source	-	--A 1-B 2-A+B 3-Switched between A B DI 4- Communication	UINT16	.	At stop
P10.1	Source of main torque reference A	-	-- Keypad 1-AI1 2-AI2	UINT16	.	At stop
P10.2	Source of main torque reference B	-	-- Keypad 1-AI1 2-AI2	UINT16	.	At stop
P10.3	Torque limit source	-	-- internal torque limit 1 1- external torque limit AI 2-Switched between external torque limit 1 and 2 selected by DI 3-Switched between external torque limit 1 and AI selected by DI 4- internal torque limit 1 and external torque limit AI	UINT16	.	Immediate
P10.4	Torque limit AI	-	1-AI1 2-AI2	UINT16	.	Immediate
P10.5	Positive internal torque limit 1	%	..~3...	UINT16	3...	Immediate
P10.6	Negative internal torque limit 1	%	..~3...	UINT16	3...	Immediate

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
P10.7	Positive internal torque limit 1	%	~3...	UINT16	3...	Immediate
P10.8	Negative internal torque limit 2	%	~3...	UINT16	3...	Immediate
P10.9	Speed limit source	-	1- Internal speed limit (in torque control)	UINT16	1	Immediate
			1- DI			
			2- AI			
P1010	Speed limit AI	-	1-AI1	UINT16	1	Immediate
			2-AI2			
P1011	Forward speed limit/1st speed limit in torque control	rpm	~6...	UINT16	3...	Immediate
P1012	Reverse speed limit/2nd speed limit in torque control	rpm	~6...	UINT16	3...	Immediate
P1013	Keypad reference in torque control	%	-3...~3...	INT16	0	Immediate
P1016	Base value for torque reach	-	~3...	UINT16	0	Immediate
P1017	Torque reach valid value	-	1...~3...	UINT16	2..	Immediate
P1018	Torque reach invalid value	-	~5393	UINT16	1..	Immediate
P1023	Field weakening selection	-	~1	UINT16	0	Immediate
P1024	Speed limit window in the torque control mode	-	0~2..	UINT16	1..	Immediate

16 Multi-Speed Function Parameters

P16..	Multi-speed operation mode	-	1- Single run	UINT16	1	At stop
			1- Cyclic operation			
			2- DI-based operation			
P16.1	Number of speed references in multispeed mode	-	1~16	UINT16	16	At stop
P16.2	Operating time unit	-	1-s	UINT16	0	At stop
			1-min			
P16.3	Acceleration time 1	ms	~60030	UINT16	1..	At stop
P16.4	Deceleration Time1	ms	~60030	UINT16	1..	At stop
P16.5	Acceleration time 2	ms	~60030	UINT16	0..	At stop
P16.6	Deceleration Time2	ms	~60030	UINT16	0..	At stop
P16.7	Acceleration time 3	ms	~60030	UINT16	1..	At stop
P16.8	Deceleration Time3	ms	~60030	UINT16	1..	At stop
P16.9	Acceleration time 4	ms	~60030	UINT16	10..	At stop
P16.10	Deceleration Time4	ms	~60030	UINT16	10..	At stop
P16.11	Speed reference 1	rpm	-6...~6...	INT16	0	At stop

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
P1621	Operating time of speed 1	P16.2	~60030	UINT16	0..	At stop
P1622	Acceleration/Deceleration time of speed 1	-	.. Zero acceleration/deceleration time	UINT16	..	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1623	Reference t 2	rpm	~600~600	INT16	1..	At stop
P1624	Operating time of speed 2	P16.2	~60030	UINT16	0..	At stop
P1625	Acceleration/Deceleration time of speed 2	-	..S	UINT16	..	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1626	Reference 3	rpm	~600~600	INT16	2..	At stop
P1627	Operating time of speed 3	P16.2	~60030	UINT16	0..	At stop
P1628	Acceleration/Deceleration time of speed 3	-	..S	UINT16	..	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1629	Reference 4	rpm	~600~600	INT16	0..	At stop
P1630	Operating time of speed 4	P16.2	~60030	UINT16	0..	At stop
P1631	Acceleration/Deceleration time of speed t 4	-	..S	UINT16	..	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1632	Reference 5	rpm	~600~600	INT16	7..	At stop
P1633	Operating time of speed 5	P16.2	~60030	UINT16	0..	At stop
P1634	Acceleration/Deceleration time of speed t 5	-	..S	UINT16	..	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1635	Reference 6	rpm	~600~600	INT16	9..	At stop
P1636	Operating time of speed 6	P16.2	~60030	UINT16	0..	At stop
P1637	Acceleration/Deceleration time of speed t 6	-	..S	UINT16	..	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1638	Reference 7	rpm	~600~600	INT16	7..	At stop
P1639	Operating time of speed 7	P16.2	~60030	UINT16	0..	At stop
P1640	Acceleration/Deceleration time of speed t 7	-	..S	UINT16	..	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1641	Reference 8	rpm	~600~600	INT16	2..	At stop

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
P1642	Operating time of speed \wedge	P16.2	..~60030	UINT16	0.	At stop
P1643	Acceleration/Deceleration time of speed t^{\wedge}	-	..-S	UINT16	0.	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1644	Reference 1	rpm	..600~600	INT16	100	At stop
P1645	Operating time of speed 1	P16.2	..~60030	UINT16	0.	At stop
P1646	Acceleration/Deceleration time of speed t^1	-	..-S	UINT16	0.	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1647	Reference 10	rpm	..600~600	INT16	-100	At stop
P1648	Operating time of speed 10	P16.2	..~60030	UINT16	0.	At stop
P1649	Acceleration/Deceleration time of speed t^{10}	-	..-S	UINT16	0.	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1650	Reference 11	rpm	..600~600	INT16	-200	At stop
P1651	Operating time of speed 11	P16.2	..~60030	UINT16	0.	At stop
P1652	Acceleration/Deceleration time of speed t^{11}	-	..-S	UINT16	0.	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1653	Reference 12	rpm	..600~600	INT16	-300	At stop
P1654	Operating time of speed 12	P16.2	..~60030	UINT16	0.	At stop
P1655	Acceleration/Deceleration time of speed t^{12}	-	..-S	UINT16	0.	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1656	Reference 13	rpm	..600~600	INT16	-400	At stop
P1657	Operating time of speed 13	P16.2	..~60030	UINT16	0.	At stop
P1658	Acceleration/Deceleration time of speed t^{13}	-	..-S	UINT16	0.	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1659	Reference 14	rpm	..600~600	INT16	-500	At stop
P1660	Operating time of speed 14	P16.2	..~60030	UINT16	0.	At stop
P1661	Acceleration/Deceleration time of speed t^{14}	-	..-S	UINT16	0.	At stop
			1- Acc/Dec time 1			
			2- Acc/Dec time 2			
			3- Acc/Dec time 3			
			4- Acc/Dec time 4			
P1662	Reference 15	rpm	..600~600	INT16	-600	At stop
P1663	Operating time of speed 15	P16.2	..~60030	UINT16	0.	At stop
P1664		-	..-S	UINT16	0.	At stop

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
	Acceleration/ Deceleration time of speed t 10		1- Acc/Dec time 1 2- Acc/Dec time 2 3- Acc/Dec time 3 4- Acc/Dec time 4			
P1660	Reference 16	rpm	-6000~6000	INT16	-300	At stop
P1661	Operating time of speed 16	P16.2	0~60020	UINT16	0	At stop
P1662	Acceleration/ Deceleration time of speed t 17	-	--S 1- Acc/Dec time 1 2- Acc/Dec time 2 3- Acc/Dec time 3 4- Acc/Dec time 4	UINT16	0	At stop
1Y Multi- Position Operation References						
P1700	Multi-position operation mode	-	-- Individual operation 1- Cyclic operation 2- DI-based operation 3- Sequential operation	UINT16	1	At stop
P1701	Number of displacement references in multiposition mode	-	1~16	UINT16	1	At stop
P1702	Starting displacement No. after pause	-	0- Continue to execute the unexecuted displacements 1- Start from displacement 1	UINT16	0	At stop
P1703	Interval time unit	-	--ms 1-s	UINT16	0	At stop
P1704	Displacement reference type	-	-- Relative displacement reference 1- Absolute displacement reference	UINT16	0	At stop
P1705	Starting displacement No. in sequential operation	-	0~16	UINT16	0	At stop
P1712	Displacement 1	Refer ence unit	-1.73741824~1.73741824	INT32	1000	Immediate
P1714	Speed of displacement 1	rpm	1~6000	UINT16	200	Immediate
P1715	Acc/Dec time of displacement 1	ms	0~60020	UINT16	10	Immediate
P1716	Interval time after displacement 1	P17.3	0~1000	UINT16	10	Immediate
P1717	Displacement 2	Refer ence unit	-1.73741824~1.73741824	INT32	1000	Immediate
P1719	Speed of displacement 2	rpm	1~6000	UINT16	200	Immediate
P1720	Acc/Dec time of displacement 2	ms	0~60020	UINT16	10	Immediate
P1721	Interval time after displacement 2	P17.3	0~1000	UINT16	10	Immediate
P1722	Displacement 3	Refer ence unit	-1.73741824~1.73741824	INT32	1000	Immediate
P1724	Speed of displacement 3	rpm	1~6000	UINT16	200	Immediate

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
P1Y20	Acc/Dec time of displacement r	ms	~60030	UINT16	1.	Immediate
P1Y21	Interval time after displacement r	P1Y03	~1....	UINT16	1.	Immediate
P1Y22	Displacement z	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1Y23	Speed of displacement z	rpm	1~6...	UINT16	2..	Immediate
P1Y24	Acc/Dec time of displacement z	ms	~60030	UINT16	1.	Immediate
P1Y25	Interval time after displacement z	P1Y03	~1....	UINT16	1.	Immediate
P1Y26	Displacement o	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1Y27	Speed of displacement o	rpm	1~6...	UINT16	2..	Immediate
P1Y28	Acc/Dec time of displacement o	ms	~60030	UINT16	1.	Immediate
P1Y29	Interval time after displacement o	P1Y03	~1....	UINT16	1.	Immediate
P1Y30	Displacement e	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1Y31	Speed of displacement e	rpm	1~6...	UINT16	2..	Immediate
P1Y32	Acc/Dec time of displacement e	ms	~60030	UINT16	1.	Immediate
P1Y33	Interval time after displacement e	P1Y03	~1....	UINT16	1.	Immediate
P1Y34	Displacement u	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1Y35	Speed of displacement u	rpm	1~6...	UINT16	2..	Immediate
P1Y36	Acc/Dec time of displacement u	ms	~60030	UINT16	1.	Immediate
P1Y37	Interval time after displacement u	P1Y03	~1....	UINT16	1.	Immediate
P1Y38	Displacement v	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1Y39	Speed of displacement v	rpm	1~6...	UINT16	2..	Immediate
P1Y40	Acc/Dec time of displacement v	ms	~60030	UINT16	1.	Immediate
P1Y41	Interval time after displacement v	P1Y03	~1....	UINT16	1.	Immediate
P1Y42	Displacement w	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1Y43	Speed of displacement w	rpm	1~6...	UINT16	2..	Immediate
P1Y44	Acc/Dec time of displacement w	ms	~60030	UINT16	1.	Immediate
P1Y45	Interval time after displacement w	P1Y03	~1....	UINT16	1.	Immediate
P1Y46	Displacement x	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1Y47	Speed of displacement x	rpm	1~6...	UINT16	2..	Immediate
P1Y48	Acc/Dec time of displacement x	ms	~60030	UINT16	1.	Immediate
P1Y49	Interval time after displacement x	P1Y03	~1....	UINT16	1.	Immediate
P1Y50	Displacement y	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1Y51	Speed of displacement y	rpm	1~6...	UINT16	2..	Immediate
P1Y52	Acc/Dec time of displacement y	ms	~60030	UINT16	1.	Immediate
P1Y53	Interval time after displacement y	P1Y03	~1....	UINT16	1.	Immediate
P1Y54	Displacement z	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1Y55	Speed of displacement z	rpm	1~6...	UINT16	2..	Immediate
P1Y56	Acc/Dec time of displacement z	ms	~60030	UINT16	1.	Immediate

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
P1706	Interval time after displacement 1	P1703	~1....	UINT16	1.	Immediate
P1707	Displacement 1.	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1709	Speed of displacement 1.	rpm	1~6...	UINT16	2..	Immediate
P1710	Acc/Dec time of displacement 1.	ms	~60030	UINT16	1.	Immediate
P1711	Interval time after displacement 1.	P1703	~1....	UINT16	1.	Immediate
P1712	Displacement 11	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1714	Speed of displacement 11	rpm	1~6...	UINT16	2..	Immediate
P1715	Acc/Dec time of displacement 11	ms	~60030	UINT16	1.	Immediate
P1716	Interval time after displacement 11	P1703	~1....	UINT16	1.	Immediate
P1717	Displacement 12	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1719	Speed of displacement 12	rpm	1~6...	UINT16	2..	Immediate
P1720	Acc/Dec time of displacement 12	ms	~60030	UINT16	1.	Immediate
P1721	Interval time after displacement 12	P1703	~1....	UINT16	1.	Immediate
P1722	Displacement 13	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1724	Speed of displacement 13	rpm	1~6...	UINT16	2..	Immediate
P1725	Acc/Dec time of displacement 13	ms	~60030	UINT16	1.	Immediate
P1726	Interval time after displacement 13	P1703	~1....	UINT16	1.	Immediate
P1727	Displacement 14	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1729	Speed of displacement 14	rpm	1~6...	UINT16	2..	Immediate
P1730	Acc/Dec time of displacement 14	ms	~60030	UINT16	1.	Immediate
P1731	Interval time after displacement 14	P1703	~1....	UINT16	1.	Immediate
P1732	Displacement 15	Reference unit	-1.73741824~1.73741824	INT32	1....	Immediate
P1734	Speed of displacement 15	rpm	1~6...	UINT16	2..	Immediate
P1735	Acc/Dec time of displacement 15	ms	~60030	UINT16	1.	Immediate
P1736	Interval time after displacement 15	P1703	~1....	UINT16	1.	Immediate

Parameter List

Param.	Name	Unit	Value	Data Type	Default	Change
P1Y8Y	Displacement ۱۶	Reference unit	-1.۰۷۳۷۴۱۸۲۴~1.۰۷۳۷۴۱۸۲۴	INT۳۲	1....	Immediate
P1Y8۹	Speed of displacement ۱۶	rpm	1~6...	UINT۱۶	2..	Immediate
P1Y9..	Acc/Dec time of displacement ۱۶	ms	.~60030	UINT۱۶	1..	Immediate
P1Y9۱	Interval time after displacement ۱۶	P1Y..۳	.~1....	UINT۱۶	1..	Immediate
P1Y9۲	Current number of segments	-	.~1..	UINT۱۶	1..	At stop

